Instruction

MI 019-202 August 2014

### I/A Series® Intelligent Vortex Model 84 Flanged (Styles A and B), Wafer, and MNPT Flowmeters with HART Communication

Installation, Operation, and Maintenance



by Schneider Electric

MI 019-202 – August 2014

# **Contents**

Figures	7
Tables	11
1. Introduction	
Overview	13
Reference Documents	13
Standard Specifications	14
Electrical Safety Specifications	25
ATEX and IECEx Warnings	
ATEX Compliance Documents	27
IECEx Compliance Documents	27
Configurable Parameters	27
2. Installation	
Fundamental Installation Requirements	
Unpacking	
Flowmeter Identification	
Mechanical Installation	
Dimensions	
Hydrostatic Piping Testing	
Piping Considerations	
Effects of Piping on Flowmeter Performance	
Liquid Installations	
Gas Installations	
Steam Installations	
Saturated Steam	
Superheated Steam	
Insulation	
Vibration	
Ambient Temperature Limitations / Considerations	
Meter Servicing	
Location of Pressure and Temperature Taps	
Mechanically Installing the Flowmeter Body	
84F – Flanged Body	
84W – Wafer Body	

Threaded (MNPT)	
Mounting the Remote Electronics Housing	
Cover Locks	
Positioning the Display	45
Setting the Write Protect Jumper	45
Positioning the Housing	
Electrical Installation	
Integrally Mounted Electronics	
Remotely Mounted Electronics	
Preparing the Remote Signal Cable	
Connecting the Remote Signal Cable	
Installation with Conduit	
Explosionproof / Flameproof Certifications	
Field Termination Wiring	
Conduit / Cable Gland Connections	
Accessing Flowmeter Field Terminals	
Wiring the Flowmeter to a Control Loop	
Multidrop Communication	
Wiring a Flowmeter With a Pulse Output	
Wiring a Flowmeter with a Pulse Output (3-Wire)	
3. Operation Via Local Display	
<b>3. Operation Via Local Display</b> Local Keypad/Display	
Local Keypad/Display	
	59 60
Local Keypad/Display Display Bar Indicator	59 60 60
Local Keypad/Display Display Bar Indicator Password	
Local Keypad/Display Display Bar Indicator Password Entering the Password Activating an Edit, Pick-List, or User Menu Block	
Local Keypad/Display Display Bar Indicator Password Entering the Password	
Local Keypad/Display Display Bar Indicator Password Entering the Password Activating an Edit, Pick-List, or User Menu Block Editing Numbers and Strings	
Local Keypad/Display Display Bar Indicator Password Entering the Password Activating an Edit, Pick-List, or User Menu Block Editing Numbers and Strings Signed Numbers	
Local Keypad/Display Display Bar Indicator Password Entering the Password Activating an Edit, Pick-List, or User Menu Block Editing Numbers and Strings Signed Numbers Unsigned Numbers	
Local Keypad/Display Display Bar Indicator Password Entering the Password Activating an Edit, Pick-List, or User Menu Block Editing Numbers and Strings Signed Numbers Unsigned Numbers Strings	
Local Keypad/Display Display Bar Indicator Password Entering the Password Activating an Edit, Pick-List, or User Menu Block Editing Numbers and Strings Signed Numbers Unsigned Numbers Strings Picking from a List Configuration Database	
Local Keypad/Display Display Bar Indicator Password Entering the Password Activating an Edit, Pick-List, or User Menu Block Editing Numbers and Strings Signed Numbers Unsigned Numbers Strings Picking from a List	
Local Keypad/Display Display Bar Indicator Password Entering the Password Activating an Edit, Pick-List, or User Menu Block Editing Numbers and Strings Signed Numbers Unsigned Numbers Strings Picking from a List Configuration Database Using the Menu Tree	
Local Keypad/Display Display Bar Indicator Password Entering the Password Activating an Edit, Pick-List, or User Menu Block Editing Numbers and Strings Signed Numbers Unsigned Numbers Strings Picking from a List Configuration Database Using the Menu Tree Moving Inside the Menu System	59 
Local Keypad/Display Display Bar Indicator Password Entering the Password Activating an Edit, Pick-List, or User Menu Block Editing Numbers and Strings Signed Numbers Unsigned Numbers Strings Picking from a List Configuration Database Using the Menu Tree Moving Inside the Menu System Top Level Menu	
Local Keypad/Display Display Bar Indicator Password Entering the Password Activating an Edit, Pick-List, or User Menu Block Editing Numbers and Strings Signed Numbers Unsigned Numbers Unsigned Numbers Strings Picking from a List Configuration Database Using the Menu Tree Moving Inside the Menu System Top Level Menu Measure Mode	59 

Setup Mode	67
Setting Fluid Parameters	68
Setting Flow Parameters	70
Setting Tuning Parameters	71
Setting Totals Parameters	71
Setting Output Parameters	72
Setting Piping Parameters	73
Setting Tag Parameters	75
Setting Flowtube Parameters	75
Changing the Password	75
Setup Menu Tree	76
Calibration/Test Mode	78
Calibration	79
Test	
Error Messages	80
Operation Error Messages	80
Configuration Error Messages	81
4. Operation Via HART Communicator	83
Online Menu	83
Explanation of Parameters	87
5. Troubleshooting	93
Flowmeter Output Indicates Flow When There Is No Flow	93
Flowmeter Has No Output (No mA Output and the Display [If So Equipped] Is Blank)	94
Flowmeter Has No Output With Flow, But Has a 4 mA Signal and a Lighted Display (If S Equipped)	
Flowmeter Output Increases With Flow, However When It Approaches Full Scale, the Ou Suddenly Goes To 4 mA	itput 95
Flowmeter with Remote Mounted Electronics Has No Output or Low Output With Flow Conditions	
Electronics Module Test	96
Flowmeter Has Incorrect Output	
6. Maintenance	99
Introduction	
Vortex Generation and Shedding	
Vortex Generation and Snedding	
-	
Electronic Module Electronic Module Removal	
Electronic Module Replacement	
	101

Removal Procedure103Installation Procedure104Preamplifier Replacement106Removal Procedure106Installation Procedure107Post-Assembly Dielectric Test107Sensor Replacement108Integrally Mounted Flowmeter108Sensor Assembly Removal108Sensor Assembly Installation109Remotely Mounted Flowmeter113Sensor Assembly Installation114Appendix A. Isolation Valves117Replacing the Sensor117Replacing or Installing an Isolation Valve118Style B Vortex Flowmeters, Single Isolation Valve120Style B Vortex Flowmeters, Dual Isolation Valve123	Neck Board Replacement	
Preamplifier Replacement106Removal Procedure106Installation Procedure107Post-Assembly Dielectric Test107Sensor Replacement108Integrally Mounted Flowmeter108Sensor Assembly Removal108Sensor Assembly Installation109Remotely Mounted Flowmeter113Sensor Assembly Removal113Sensor Assembly Installation114Appendix A. Isolation Valves117Replacing the Sensor117Replacing or Installing an Isolation Valve118Style B Vortex Flowmeters, Single Isolation Valve120	Removal Procedure	
Removal Procedure106Installation Procedure107Post-Assembly Dielectric Test107Sensor Replacement108Integrally Mounted Flowmeter108Sensor Assembly Removal108Sensor Assembly Installation109Remotely Mounted Flowmeter113Sensor Assembly Removal113Sensor Assembly Installation114Appendix A. Isolation Valves117Replacing the Sensor117Replacing or Installing an Isolation Valve118Style A Vortex Flowmeters118Style B Vortex Flowmeters, Single Isolation Valve120	Installation Procedure	
Installation Procedure107Post-Assembly Dielectric Test107Sensor Replacement108Integrally Mounted Flowmeter108Sensor Assembly Removal108Sensor Assembly Installation109Remotely Mounted Flowmeter113Sensor Assembly Removal113Sensor Assembly Installation114Appendix A. Isolation Valves117Replacing the Sensor117Replacing or Installing an Isolation Valve118Style A Vortex Flowmeters118Style B Vortex Flowmeters, Single Isolation Valve120	Preamplifier Replacement	
Post-Assembly Dielectric Test107Sensor Replacement108Integrally Mounted Flowmeter108Sensor Assembly Removal108Sensor Assembly Installation109Remotely Mounted Flowmeter113Sensor Assembly Removal113Sensor Assembly Removal113Sensor Assembly Installation117Remotely Mounted Flowmeter117Replacing the Sensor117Replacing the Sensor117Replacing or Installing an Isolation Valve118Style A Vortex Flowmeters118Style B Vortex Flowmeters, Single Isolation Valve120	Removal Procedure	
Sensor Replacement108Integrally Mounted Flowmeter108Sensor Assembly Removal108Sensor Assembly Installation109Remotely Mounted Flowmeter113Sensor Assembly Removal113Sensor Assembly Installation114Appendix A. Isolation Valves117Replacing the Sensor117Replacing or Installing an Isolation Valve118Style B Vortex Flowmeters118Style B Vortex Flowmeters, Single Isolation Valve120	Installation Procedure	
Integrally Mounted Flowmeter       108         Sensor Assembly Removal       108         Sensor Assembly Installation       109         Remotely Mounted Flowmeter       113         Sensor Assembly Removal       113         Sensor Assembly Removal       113         Sensor Assembly Installation       114         Appendix A. Isolation Valves       117         Replacing the Sensor       117         Replacing or Installing an Isolation Valve       118         Style A Vortex Flowmeters       118         Style B Vortex Flowmeters, Single Isolation Valve       120	Post-Assembly Dielectric Test	
Sensor Assembly Removal       108         Sensor Assembly Installation       109         Remotely Mounted Flowmeter       113         Sensor Assembly Removal       113         Sensor Assembly Installation       114         Appendix A. Isolation Valves       117         Replacing the Sensor       117         Replacing or Installing an Isolation Valve       118         Style A Vortex Flowmeters       118         Style B Vortex Flowmeters, Single Isolation Valve       120	Sensor Replacement	
Sensor Assembly Installation109Remotely Mounted Flowmeter113Sensor Assembly Removal113Sensor Assembly Installation114Appendix A. Isolation Valves117Replacing the Sensor117Replacing or Installing an Isolation Valve118Style A Vortex Flowmeters118Style B Vortex Flowmeters, Single Isolation Valve120	Integrally Mounted Flowmeter	
Remotely Mounted Flowmeter       113         Sensor Assembly Removal       113         Sensor Assembly Installation       114         Appendix A. Isolation Valves       117         Replacing the Sensor       117         Replacing or Installing an Isolation Valve       118         Style A Vortex Flowmeters       118         Style B Vortex Flowmeters, Single Isolation Valve       120	Sensor Assembly Removal	
Sensor Assembly Removal	Sensor Assembly Installation	
Sensor Assembly Installation	Remotely Mounted Flowmeter	
Appendix A. Isolation Valves       117         Replacing the Sensor       117         Replacing or Installing an Isolation Valve       118         Style A Vortex Flowmeters       118         Style B Vortex Flowmeters, Single Isolation Valve       120	Sensor Assembly Removal	
Replacing the Sensor	Sensor Assembly Installation	
Replacing or Installing an Isolation Valve	Appendix A. Isolation Valves	
Style A Vortex Flowmeters	Replacing the Sensor	
Style A Vortex Flowmeters	Replacing or Installing an Isolation Valve	
	Style B Vortex Flowmeters, Single Isolation Valve	
	Style B Vortex Flowmeters, Dual Isolation Valve	

# *Figures*

1	ANSI Flange Ratings; per ASME B16.5; Group 2.2 Materials; Standard Pressure Options: Style A: Cast Tubes (3/4 to 4 Inch, CF8M) and Flanges (CF8M, 4-inch Class 150 with
	Welded Slip-On Flanges) Style B: Cast Tubes (3/4 to 4 Inch, CF8M) and Welded Weld-Neck Flanges (316 SS) .16
2	ANSI Flange Ratings; per ASME B16.5; Group 2.2 Materials; High Pressure Options:
	Style B Only: Cast Tubes (3/4 to 4 Inch, CF8M) and Welded Weld-Neck Flanges
	(316 SS)
3	ANSI Flange Ratings; per ASME B16.5; Group 2.1 Materials; Standard Pressure Options:
	Style A: Fabricated Tubes (6 to 12 Inch, 304 SS) and Welded Flanges (304 SS)
,	Style B: Cast Tubes (6 to 12 Inch, CF8M) and Welded Weld-Neck Flanges (304 SS) 17
4	ANSI Flange Ratings; per ASME B16.5; Group 1.1 Materials; Standard Pressure Options:
	Style A: Fabricated Tubes (3/4 to 12 Inch, 304 SS) and Welded Flanges (Carbon Steel)
	Style B: Cast Tubes (3/4 to 12 Inch, CF8M) and Welded Weld-Neck Flanges
F	(Carbon Steel)
5	Style B Only: Cast Tubes (3/4 to 8 Inch, CF8M), and Welded Weld-Neck Flanges
	(Carbon Steel)
6	ANSI Flange Ratings; per ASME B16.5; Group 2.8 Materials; Standard Pressure Options:
0	Style B Only: Cast Tubes (3/4 to 12 Inch, CD3MN Duplex SS), and Welded Weld-Neck
	Flanges (ASTM A182 Gr. F51 Duplex SS)
7	ANSI Flange Ratings; per ASME B16.5; Group 2.8 Materials; High Pressure Options:
	Style B Only: Cast Tubes (3/4 to 8 Inch, CD3MN Duplex SS) and Welded Weld-Neck
	Flanges (ASTM A182 Gr. F51 Duplex SS)19
8	ANSI Flange Ratings; per ASME B16.5; Group 3.8 Materials; Standard Pressure Options:
	Style B Only: Cast Tubes (3/4 to 12 Inch, CX2MW Nickel Alloy [equivalent to
	Hastelloy® C-22]) and Welded Weld-Neck Flanges (N06022 [equivalent to Hastelloy®
	C-22])
9	ANSI Flange Ratings; per ASME B16.5; Group 3.8 Materials; High Pressure Options:
	Style B Only: Cast Tubes (3/4 to 8 Inch, CX2MW Nickel Alloy [equivalent to
	Hastelloy® C-22]), and Welded Weld-Neck Flanges (N06022 [equivalent to Hastelloy®
10	C-22])
10	Style A: Cast Tubes (DN15 to DN100, CF8M) and Flanges (CF8M, 4-inch Class 150
	with Welded Slip-On Flanges)
	Style B: Cast Tubes (DN15 to DN100, CF8M) and Welded Weld-Neck Flanges
	(316 SS)
11	Metric Flange Ratings; per EN 1092-1; Material Group 10E0s:
	Style A: Fabricated Tubes (DN150 to DN300, 304 SS) and Welded Weld-Neck Flanges
	(304 SS)
	Style B: Cast Tubes (DN150 to DN300, CF8M) and Welded Weld-Neck Flanges
	(304 SS)
	I

12	Metric Flange Ratings; per EN 1092-1; Material Group 3E0:		
	Style A: Fabricated Tubes, (DN150 to DN300, 304 SS) and Welded Weld-Neck Flanges		
	(Carbon Steel)		
	Style B: Cast Tubes (DN15 to DN300, CF8M) and Welded Weld-Neck Flanges		
	(Carbon Steel)		
13	Metric Flange Ratings; per EN 1092-1; Material Group 16E0; Standard Pressure Options:		
10	Style B Only: Cast Tubes, DN150 to DN300 Duplex Materials, and Welded Weld-Neck		
	Flanges		
14	Pressure - Temperature Limits with Isolation Valves		
15	Sample Flowmeter Data Plate		
16	Sample Junction Box Data Plate		
10			
	Piping Arrangements		
18	Piping for Gas Applications		
19	Piping for Saturated Steam Applications		
20	Insulation		
21	Sensor Mounting to Minimize Effect of Vibration		
22	Typical Piping Configuration40		
23	Pressure and Temperature Tap Locations		
24	84F Flowmeter Installation		
25	84W Flowmeter Centering (using Spacers)		
26	Mounting the Remote Electronics Housing44		
27	Cover Locks		
28	Write Protect Jumper		
29	Housing Screw or Clip Location		
30	Connection of Remote Signal Cable (Junction Box End)		
31	Accessing Field Terminals		
32	Identification of Field Terminals		
33	Supply Voltage and Loop Load		
34	Loop Wiring 4 to 20 mÅ Output Flowmeters		
35	Typical Multidrop Network		
36	Wiring an 84F-T (Styles A and B) or 84W-T Flowmeter with a Pulse Output Transistor		
	Switch (sinking) Counter Input with Receiver Supplied Power		
37	Wiring an 84F-T (Styles A and B) or 84W-T Flowmeter with a Pulse Output		
0,	Transistor Switch (sinking) Counter Input with External Power Supply and Pull-Up		
	Resistor		
38	Wiring an 84F-T (Styles A and B) or 84W-T Flowmeter with a Pulse Output		
50	Transistor Switch (sourcing) Counter Input with External Power Supply and Pull-Up		
	Resistor		
39	Wiring an 84F-T (Styles A and B) or 84W-T Flowmeter with a Pulse Output		
57	Using a 3-Wire Hookup		
40	e i		
40 41	Local Display		
	Top Level Modes and Their Basic Functions		
42	Status Mode Structure Diagram		
43	View Mode Structure Diagram		
44	Piping Configurations		
45	Setup Menu Tree (1 of 3)		
46	Setup Menu Tree (2 of 3)		
47	Setup Menu Tree (3 of 3)		

Calibration/Test Menu Tree	80
84 Vortex Flowmeter Online Menu Tree (1 of 4)	83
84 Vortex Flowmeter Online Menu Tree (2 of 4)	84
84 Vortex Flowmeter Online Menu Tree (3 of 4)	85
84 Vortex Flowmeter Online Menu Tree (4 of 4)	86
Electronic Module Connections	101
Display Connection	102
Preamplifier Assembly - Integrally Mounted	104
Preamplifier Assembly - Remotely Mounted	
Connections for Post-Assembly Dielectric Test	107
Sensor Replacement - Remotely Mounted Flowmeter	
Bonnet Bolt Torquing Sequence	118
Single Isolation Valve (Style A)	119
Dual Isolation Manifold (Style A)	120
Bonnet Bolt Torquing Sequence	121
Single Isolation Valve (Style B)	
Bonnet Bolt Torquing Sequence	
Dual Isolation Manifold (Style B)	
	84 Vortex Flowmeter Online Menu Tree (1 of 4)

# **Tables**

1	Nominal Flow Velocity Limits	15
2	Electrical Safety Specifications	25
3	Configurable Parameters	27
4	Mounting Arrangements	
5	Preparation of Remote Signal Cable (Junction Box End)	47
6	Operation of Function Keys	60
7	Default Database When User Information Not Supplied	62
8	Default Database for Liquid	62
9	Default Database for Gas	62
10	Default Database for Steam	
11	Available Engineering Units	69
12	All Flow EGU Descriptions (Volume, Mass, Base Volume, and Velocity)	69
13	Viscosity, K-Factor, Density, and Temperature EGU Descriptions	70
14	Operation Error Messages	81
15	Configuration Error Messages	81
16	Electronic Module Terminal Block Connections	
17	Maximum Test Pressure	113

# 1. Introduction

### Overview

The 84F-T (Styles A and B), 84F-U (Styles A and B), 84W-T, and 84W-U Vortex Flowmeters measure fluid (liquid, gas, or steam) flow rates using the principle of vortex shedding. The flowmeters produce a digital signal (HART protocol) and a 4-20 mA analog signal. The 84F-T (Styles A and B) and 84W-T also produce a pulse signal proportional to the volumetric flow rate.

Fluid flowing through the flowmeter body passes a specially shaped vortex shedder that causes vortices to form and shed alternately from the sides of the shedder at a rate proportional to the flow rate of the fluid. These shedding vortices create an alternating differential pressure that is sensed by a detector located above the shedder. A pulsed voltage is generated by the detector with a frequency that is synchronous with the vortex shedding frequency. This signal is then conditioned by an Electronic Module and processed by the microcontroller to produce a digital signal, an analog (4-20 mA dc) signal, and in the 84F-T (Styles A and B) and 84W-T a pulse signal.

The flowmeter allows direct analog connection to common receivers while still providing full digital communications using a HART Communicator or a PC-Based configurator.

Style A Vortex meters have flanges cast for 3/4 through 4 inch line sizes. For 6 to 12 inch line sizes, Style A Vortex meters have a modular design with pipe centerbody and welded flanges. This style will be replaced by Style B incrementally as new castings become available, starting in 2011.

The Style B Vortex meter has a modular design with cast centerbody and welded flanges. The standard face-to-face of Style B is different from Style A for some models and backward compatible face-to-face are available as an option. Style B offers new materials such as Duplex SS, and nickel alloy CX2MW (equivalent to Hastelloy<sup>®</sup> C-22<sup>(1)</sup>) and high-pressure options to Class 1500 and PN160. The Style B Vortex is also offered with a MNPT (Male National Pipe Thread) end connection in 3/4 inch through 2 inch line sizes.

## **Reference Documents**

In addition to this instruction, there is other user documentation supporting the 84F-T (Styles A and B), 84F-U (Styles A and B), 84W-T, and 84W-U Vortex Flowmeters, as listed below.

Document Number	Document Description	
Dimensional Prints		
DP 019-12084F Style A Flanged Body — Single Measurement ConfigurationDP 019-12184F Style A Flanged Body — Dual Measurement ConfigurationDP 019-12584F Style B Flanged Body — Single Measurement ConfigurationDP 019-12684F Style B Flanged Body — Dual Measurement ConfigurationDP 019-12284W Wafer Body		
Parts Lists		
PL 008-714 84F Style A Flanged and 84W Wafer Body Flowmeters		

1. Hastelloy® is a registered trademark of Haynes International Inc.

Document Number Document Description		
PL 008-753 84F Style B Flanged Body Flowmeters		
Technical Information and Instructions		
B0800AJEnsuring Premium Performance with Foxboro 84 Series Vortex FlowmetersMI 019-14683 and 84 I/A Series Intelligent Vortex Flowmeter Universal Instruction ManuMI 019-17784 Vortex Flowmeter FM and CSA Connection DiagramsMI 019-179Flow Products Safety Information (a)		

a. Available in many languages online at

www.ips.invensys.com/en/products/measurement/Pages/SafetyInstructionsforFlow.aspx

### Standard Specifications

Process Temperature Limits:

Standard Temp/Fluorolube Fill: –20 and +90°C (0 and 200°F) Nickel alloy CW2M (equivalent to Hastelloy  $^{\mbox{${\rm R}$}}$  C-4C  $^{(1)}$ )

Standard Temp/Fluorolube Fill: -20 and +90°C (0 and 200°F) Stainless Steel Type CF3M

Standard Temp/Silicone Fill: –20 and +200°C (0 and 400°F) Nickel alloy CW2M (equivalent to Hastelloy<sup>®</sup> C-4C<sup>1</sup>)

Standard Temp/Silicone Fill: -20 and +200°C (0 and 400°F) Stainless Steel Type CF3M

High Temp/Unfilled: 200 and 430°C (400 and 800°F)

Ambient Temperature Limits:

With Indicator: -20 and  $+80^{\circ}C$  (0 and  $+176^{\circ}F$ )

Without Indicator: -40 and +80°C (-40 and +176°F)

Power Supply Requirements:

Supply Voltage Limits: 15.5 and 42 V dc

Supply Current:

Digital Mode: 10 mA dc nominal

Analog Mode: 22 mA dc maximum

Reynolds Number Requirements

Rd = 5000 minimum; Automatic compensation for the nonlinear behavior of vortex shedding in the Rd range 5000 to 20,000 is built into the flowmeter. This compensation requires the user to input values for the flowing density and viscosity. Best accuracy is achieved at higher Reynolds numbers (>30,000 Rd).

Nominal Flow Velocity Limits: Can be calculated per Table 1.

<sup>1.</sup> Hastelloy® is a registered trademark of Haynes International Inc.

Range	Std. Temp. Range		High Temp. Range	
Limit	ft/s	m/s	ft/s	m/s
Lower	$2.5/\sqrt{\rho_{f}}$	$3.0/\sqrt{\rho_{f}}$	$5.0/\sqrt{\rho_{f}}$	$6.0/\sqrt{\rho_{f}}$
Upper	$250/\sqrt{\rho_f}$	$300/\sqrt{\rho_f}$	$250/\sqrt{\rho_f}$	$300/\sqrt{\rho_f}$

Table 1. Nominal Flow Velocity Limits

#### - NOTE

The calculations in Table 1 apply for many applications but as they only provide nominal limits, Invensys recommends using the FlowExpert Pro<sup>™</sup> sizing program for your specific application.

#### Static Pressure Limits:

Minimum: Pressure sufficient to prevent flashing and meet the pressure drop requirements to attain maximum flow rate. Refer to the FlowExpertPro sizing program.

Maximum: Determined by flange rating.

#### Flowmeter Output:

Analog: 4 to 20 mA dc into a maximum 1350 ohm load depending on power supply (see Figure 33).

Digital (HART): Digital signal conveyed at 1200 Baud transmission rates via Frequency Shift Keying (FSK) tones superimposed on power supply leads.

Pulse Output in 84F-T (Styles A and B) and 84W-T only: Isolated 2 wire transistor switch.

Pulse rate (0 to 10, 100, or 1000 Hz) proportional to volumetric flow rate or total flow.

#### - NOTE

Accuracy of 0 to 10 Hz pulse rate is  $\pm 0.1\%$  from 3 to 10 Hz and  $\pm 0.3\%$  from 0 to 3 Hz.

Pulse Output Specifications

Isolated 2-wire transistor switch

Applied voltage: 5 to 30 V dc

Maximum 'ON' state voltage drop: 1.0 V dc

Maximum 'ON' state current: 20 mA dc

Reverse polarity protected

Short Circuit protected

Connectable to pull-up and pull-down counters

Maximum Working Pressure:

84F Flanged Body Flowmeters

The maximum working pressure (MWP) of the flowtube at 100°F is shown on the data label.

The MWP at other temperatures for the 84F Flanged Body Flowmeter without isolation valve is given in Figure through Figure 12. The nominal line size, body and flange material, and flange rating required to use these figures is found within the model number on the data label as follows:




Figure 1. ANSI Flange Ratings; per ASME B16.5; Group 2.2 Materials; Standard Pressure Options: Style A: Cast Tubes (3/4 to 4 Inch, CF8M) and Flanges (CF8M, 4-inch Class 150 with Welded Slip-On Flanges)

Style B: Cast Tubes (3/4 to 4 Inch, CF8M) and Welded Weld-Neck Flanges (316 SS)




Figure 2. ANSI Flange Ratings; per ASME B16.5; Group 2.2 Materials; High Pressure Options: Style B Only: Cast Tubes (3/4 to 4 Inch, CF8M) and Welded Weld-Neck Flanges (316 SS)




Figure 3. ANSI Flange Ratings; per ASME B16.5; Group 2.1 Materials; Standard Pressure Options: Style A: Fabricated Tubes (6 to 12 Inch, 304 SS) and Welded Flanges (304 SS) Style B: Cast Tubes (6 to 12 Inch, CF8M) and Welded Weld-Neck Flanges (304 SS)




Figure 4. ANSI Flange Ratings; per ASME B16.5; Group 1.1 Materials; Standard Pressure Options: Style A: Fabricated Tubes (3/4 to 12 Inch, 304 SS) and Welded Flanges (Carbon Steel) Style B: Cast Tubes (3/4 to 12 Inch, CF8M) and Welded Weld-Neck Flanges (Carbon Steel)





Figure 5. ANSI Flange Ratings; per ASME B16.5; Group 1.1 Materials; High Pressure Options: Style B Only: Cast Tubes (3/4 to 8 Inch, CF8M), and Welded Weld-Neck Flanges (Carbon Steel)



#### Figure 6. ANSI Flange Ratings; per ASME B16.5; Group 2.8 Materials; Standard Pressure Options: Style B Only: Cast Tubes (3/4 to 12 Inch, CD3MN Duplex SS), and Welded Weld-Neck Flanges (ASTM A182 Gr. F51 Duplex SS)





Figure 7. ANSI Flange Ratings; per ASME B16.5; Group 2.8 Materials; High Pressure Options: Style B Only: Cast Tubes (3/4 to 8 Inch, CD3MN Duplex SS) and Welded Weld-Neck Flanges (ASTM A182 Gr. F51 Duplex SS)



#### Figure 8. ANSI Flange Ratings; per ASME B16.5; Group 3.8 Materials; Standard Pressure Options: Style B Only: Cast Tubes (3/4 to 12 Inch, CX2MW Nickel Alloy [equivalent to Hastelloy® C-22]) and Welded Weld-Neck Flanges (N06022 [equivalent to Hastelloy® C-22])




Figure 9. ANSI Flange Ratings; per ASME B16.5; Group 3.8 Materials; High Pressure Options: Style B Only: Cast Tubes (3/4 to 8 Inch, CX2MW Nickel Alloy [equivalent to Hastelloy® C-22]), and Welded Weld-Neck Flanges (N06022 [equivalent to Hastelloy® C-22])




Figure 10. Metric Flange Ratings; per EN 1092-1; Material Group 14E0 Materials: Style A: Cast Tubes (DN15 to DN100, CF8M) and Flanges (CF8M, 4-inch Class 150 with Welded Slip-On Flanges)

Style B: Cast Tubes (DN15 to DN100, CF8M) and Welded Weld-Neck Flanges (316 SS)




Figure 11. Metric Flange Ratings; per EN 1092-1; Material Group 10E0s: Style A: Fabricated Tubes (DN150 to DN300, 304 SS) and Welded Weld-Neck Flanges (304 SS) Style B: Cast Tubes (DN150 to DN300, CF8M) and Welded Weld-Neck Flanges (304 SS)




Figure 12. Metric Flange Ratings; per EN 1092-1; Material Group 3E0: Style A: Fabricated Tubes, (DN150 to DN300, 304 SS) and Welded Weld-Neck Flanges (Carbon Steel) Style B: Cast Tubes (DN15 to DN300, CF8M) and Welded Weld-Neck Flanges (Carbon Steel)





Figure 13. Metric Flange Ratings; per EN 1092-1; Material Group 16E0; Standard Pressure Options: Style B Only: Cast Tubes, DN150 to DN300 Duplex Materials, and Welded Weld-Neck Flanges



#### Isolation Valves

Flowmeters equipped with an isolation valve have Pressure-Temperature limits as shown in Figure 14. The temperature range of your flowmeter is found within the model number on the data label as follows:

84F-T02S2KDTJK

•••		
	– TEMPERATURE RANGE –––	
	- ISOLATION VALVE (K or L)	EXT TEMP = C or T




Figure 14. Pressure - Temperature Limits with Isolation Valves

84W Wafer Body Flowmeters

The maximum working pressure (MWP) of the flowtube at 100°F is shown on the data label. The wafers are designed for a maximum Class 600 working pressure.

#### Threaded (MNPT) Vortex Meters

The maximum working pressure (MWP) for 3/4" to 1.5" flowmeters is equivalent to ASME Class 1500. For 2" schedule 80 (end connection "-V") flowmeters the pressure rating is comparable to ASME Class 900 whereas for 2" schedule 160 (end connection "-W") flowmeters the pressure rating is comparable to ASME Class 1500.

## **Electrical Safety Specifications**

#### - NOTE

- 1. These flowmeters have been designed to meet the electrical safety descriptions listed in Table 2. For detailed information or status of testing laboratory approvals/certifications, contact Invensys.
- 2. See MI 019-179 for additional ATEX and IECEx safety information.
- 3. With intrinsically safe approvals and certifications with a 24 V dc supply, an active barrier is required.

Agency Certification, Types of Protection, and Area Classification	Application Conditions	Electrical Safety Design Code
ATEX intrinsically safe: II 1G II 2D Ex ia IIC T4 Ga Ex tb IIIC T103°C Db	Sira 06ATEX2067X Integrally mounted or remote mounted (electronics and junction box). Temperature Class T4; Ta = -40° to +80°C	E
ATEX flameproof: II 2/1 (1) G II 2D Ex d [ia Ga] ia IIC T4 Gb Ex tb IIIC T85°C Db	Sira 06ATEX2067X Integrally mounted electronics. Temperature Class T4; Ta = -20° to +80°C	Н
ATEX flameproof: II 2/1 (1) G II 2D Ex d [ia Ga] IIC T4 Gb Ex tb IIIC T85°C Db	Sira 06ATEX2067X Electronics housing of remote mounted version. Temperature Class T4; Ta = -20° to +80°C	
<b>CSA</b> intrinsically safe for Class I, II, III, Div. 1, Groups A, B, C, D, E, F, and G. Also, Zone certified intrinsically safe Ex ia IIC	Temperature Class T4; Ta = -40° to +80°C	С

Table 2	2. Ele	ctrical	Safety	Speci	ifications
---------	--------	---------	--------	-------	------------

Agency Certification, Types of Protection, and Area Classification	Application Conditions	Electrical Safety Design Code
<b>CSA</b> explosionproof with IS sensor connection for Class I, Div. 1, Groups B, C, and D; dust-ignitionproof for Class II, Div. 1, Groups E, F, and G; Class III, Div. 1	Temperature Class T5; Ta = 60°C	D
Also Zone certified Ex d [ia] IIC.	Temperature Class T5; Ta = -40° to +80°C	
<b>CSA</b> for Class I, Div. 2, Groups A, B, C, and D; Class II, Div. 2, Groups F and G; Class III, Div. 2.	Temperature Class T4; T = 80°C	М
<b>FM</b> intrinsically safe for Class I, II, III, Div. 1, Groups A, B, C, D, E, F, G. Also, Zone approved AEx ia IIC	Connect per MI 019-177. Temperature Class T4; Ta = 80°C	F
FM explosionproof with IS sensor connection for Class I, Div. 1, Groups B, C, and D; dust-ignitionproof for Class II, Div. 1, Groups E, F, and G; Class III, Div. 1	Connect per MI 019-177. Temperature Class T5; Ta = 85°C	G
<b>FM</b> nonincendive for Class I, Div. 2, Groups A, B, C, and D; Class II, Div. 2, Groups F and G; Class III, Div. 2	Connect per MI 019-177. Temperature Class T4; Ta = 80°C	К
<b>IECEx</b> intrinsically safe: Ex ia IIC T4 Ga Ex tb IIIC T103°C Db	IECEx SIR 06.0020X Temperature Class T4; Ta = -40° to +80°C	L
<b>IECEx</b> flameproof: Ex d [ia Ga] ia IIC T4 Gb Ex tb IIIC T85°C Db	IECEx SIR 06.0020X Integrally mounted electronics. Temperature Class T4; Ta = -20° to +80°C	В
<b>IECEx</b> flameproof: Ex d [ia Ga] IIC T4 Gb Ex tb IIIC T85°C Db	IECEx SIR 06.0020X Electronic housing of remote mounted version. Temperature Class T4; Ta = -20° to +80°C	
<b>NEPSI</b> intrinsically safe, Zone 0, Ex ia IIC	Temperature Class T4; Ta = -40° to +80°C	R
<b>NEPSI</b> flameproof, Zone 1, Ex d IIC (except acetylene)	Temperature Class T5; Ta = -40° to +85°C	S
Unit with CE mark and PED controls and 1	records	Y
Unit does not have CE mark; not to be insta	alled in European Union (EU) countries	Z

#### Table 2. Electrical Safety Specifications (Continued)

### ATEX and IECEx Warnings

Ensure area is known to be nonhazardous before removing cover.

To prevent ignition of flammable or combustible atmospheres, disconnect power before servicing.

Explosion Hazard - Do not disconnect equipment unless poser has been turned off or the area is known to be nonhazardous.

Explosion Hazard - Substitution of components may impair safety.

Do not open while circuits are alive.

### **ATEX Compliance Documents**

EN 60079-1:2007EN 60079-26:2007 EN 60079-31:2008IEC 60079-0:2011 IEC 60079-11:2011

### **IECEx Compliance Documents**

IEC 60079-0:2011 Ed 6 IEC 60079-1:2007 Ed 6 IEC 60079-11:2011 Ed 6 IEC 60079-26:2007 Ed 2 IEC 60079-31:2008 Ed 1

## **Configurable Parameters**

Table 3 lists all of the configurable parameters and the factory default for the 84 Vortex Flowmeter.

				Configurable with		
Parameter	Parameter Name	Capability	Factory Default	Integral Indicator	HART Comm.	PC-Based Config.
Fluid	2 Fluid					
Fluid Type	3 New	Gas, Liquid, Steam	Liquid	Yes	Yes	Yes
Fluid Name	3 Name		Water	Yes	Yes	Yes
Temperature Unit	3 TmpEGU	degK, degF, degC, degR	deg F	Yes	Yes	Yes
Flow Temperature	3 FlwTmp		70	Yes	Yes	Yes
Density Unit	3 DenEGU	Pick list of density units	lb/ft <sup>3</sup>	Yes	Yes	Yes
Flow Density	3 FlwDen		62.315	Yes	Yes	Yes
Base Density	3 BasDen		62.378	Yes	Yes	Yes
Viscosity Unit	3 VisEGU	cPoise or cStoke	cP	Yes	Yes	Yes
Viscosity	3 Visc		0.98	Yes	Yes	Yes
Flow	2 Flow	•				
Flow Type	3 FlwMap	VolFlow, BVolFlow, MassFlow, Velocity	VolFlow	Yes	Yes	Yes
Flow Units	3 FlwEGU	Picklist	gal/min	Yes	Yes	Yes
Flow Upper Range Value	3 FlwURV		232.73	Yes	Yes	Yes
Flow Damping Factor	3 FlwDmp	Pick list of 8 choices from 0 to 32 s	2	Yes	Yes	Yes
Flow Velocity Unit	3 VelEGU	Picklist	ft/s	Yes	No	No
Tuning	2 Tuning	•				
Signal Conditioning	3AddDrop	On or Off	On	Yes	Yes	Yes
Reynolds Number Correction	3 ReyCor	On or Off	Off	Yes	Yes	Yes
Low Flow Cut-In Level	3 LFCI	1 through 8	4	Yes	Yes	Yes
Total	2 Total					

#### Table 3. Configurable Parameters

				Configurable with		e with
Parameter	Parameter Name	Capability	Factory Default	Integral Indicator	HART Comm.	PC-Based Config.
Net Total	3 TotNet					
Мар	4 Map	Volume, Mass, BVolume	Volume	Yes	Yes	Yes
EGU	4 EGU	Pick list dependent on Mapping	m <sup>3</sup>	Yes	Yes	Yes
Grand Total	3 TotGrd					
Мар	4 Map	Volume, Mass, BVolume	Volume	Yes	Yes	Yes
EGU	4 EGU	Pick list dependent on Mapping	m <sup>3</sup>	Yes	Yes	Yes
Output	2 Output					
Coms	3 Coms					
Poll Address	4PolAdr	0 through 15	0	Yes	Yes	Yes
Preambles	4Preambl	2 to 20	5	Yes	Yes	Yes
Fail	3 Fail	Downscale or Upscale	Down- scale	Yes	Yes	Yes
Pulse	3 Pulse					
Pulse	4 Pulse	Raw, Rate, Total	Rate	Yes	Yes	Yes
(If Raw)	Pul=Raw			Yes	Yes	Yes
(If Rate)					•	
Upper Freq End Point	4 Freq	10, 100, 1000	1000	Yes	Yes	Yes
(If Total)					•	
Pulse Width	4 Pwidth		50 ms	Yes	Yes	Yes
Units	4 EGU		ft <sup>3</sup>	Yes	Yes	Yes
Units per Pulse	4 U/Pulse		1	Yes	Yes	Yes
Display	3Display				•	
Show	4 Show	FlwVol, TotNet, TotGrd (measurements to be displayed and their format)	FlwVol	Yes	Yes	Yes
First Measurement	Show1st	FlwVol, Velcty, FlwBVo, FlwMas, Raw	FlwVol	Yes	Yes	Yes
Cycle	4 Cycle	Automatic or Manual	Auto	Yes	Yes	Yes
Pipe	2 Pipe					
Piping	3 Piping					
Configuration	4 Config	Picklist of 8 configurations	Straight	Yes	Yes	Yes
Upstream Distance	4 UpDist	(in pipe diameters)	0	Yes	Yes	Yes
Bore Size	3 BorSch	Picklist of 8 choices	Sched 40	Yes	Yes	Yes
Tags	2 Tags					
HART Description	3 HrtDes	(16 characters maximum)	HART Description	Yes	Yes	Yes
HART Tag	3 HrtTag	(8 characters maximum)	HART Tag	Yes	Yes	Yes
HART Message		32 characters maximum	HART Message	No	Yes	Yes
Flowtube	2NewTube					
Model Number	3 Model	(16 characters maximum)	84F-T02 S1SSTJF	Yes	Yes	Yes
Custom Design	3 Special		·	·	•	•

Table 3.	Configura	ble Parameters	(Continued)

				Configurable with		e with
Parameter	Parameter Name	Capability	Factory Default	Integral Indicator	HART Comm.	PC-Based Config.
Flowtube Diameter	4 TubDia	Flowtube diameter in meters	0.0491998	Yes	Yes	Yes
Coef of Expansion	4 TubAlp	(in m/m/°K)	1.7262e <sup>-5</sup>	Yes	Yes	Yes
LFCI User Factor	4 LfUFac		1.0	Yes	Yes	Yes
Reference Number	3 Ref No	(16 characters maximum)	123456789 abcdefg	Yes	Yes	Yes
K-Reference	3 K Ref					
K-Factor Unit	4 K EGU	p/l, p/ft <sup>3</sup>	p/ft <sup>3</sup>	Yes	Yes	Yes
Reference K-Factor	4 K Ref	(from flowmeter tag)	258	Yes	Yes	Yes
Password	2 Passwd	·				
Password to reset Net and Pulse Totalizer	3 LoPwd	(4 characters)	(4 spaces)	Yes	No	No
Password for all functions	3 HiPwd	(4 characters)	(4 spaces)	Yes	No	No

### Table 3. Configurable Parameters (Continued)

# 2. Installation

## Fundamental Installation Requirements

These flowmeters must be installed by trained personnel to meet all applicable local installation regulations, such as hazardous location requirements, electrical wiring codes, and mechanical piping codes. The transmitter housing must be grounded to insure proper operation and peak performance.

This chapter outlines recommendations that provide the highest level of flowmeter performance for your process.

## Unpacking

Your 84 Series Vortex Flowmeter is built to be durable, but it is part of a calibrated precision system and should be handled as such.

#### - NOTE

84W Flowmeters may (depending on pressure rating of flanges with which they are used) have a set of centering spacers included. Do **not** discard these centering spacers. They must be used to install the flowmeter properly.

Flowmeters with remote-mounted electronics have a cable connecting the flowmeter junction box and electronics housing. Do **not** allow the weight of either the flowmeter body or electronics housing to be supported by the remote cable.

Remove the flowmeter body from the shipping carton using care to avoid dropping or otherwise subjecting it to impact, particularly at the flange or wafer faces. Never put anything through the flowmeter body for lifting purposes as damage to the shedder bar may occur.

After removing the flowmeter body from its shipping carton, inspect it for visible damage. If any damage is observed, notify the carrier immediately and request an inspection report. Obtain a signed copy of the report from the carrier. The calibration certificate and any other documentation shipped with the meter should be separated from the packing material and held for future reference. Re-install any flange covers or protective material to safeguard the meter until it is installed.

Packing material should be disposed of in accordance with local regulations. All packing material is nonhazardous and is generally acceptable to landfills.

### Flowmeter Identification

Before installing your flowmeter, check its data plate to assure that it is correct for your application. Specifications such as maximum ambient temperature, process temperature, and working pressure are given on the data plate. The model code is also stamped on the data plate as shown in Figure 15 and is digitally readable from the configuration menu. On flowmeters with remotely mounted electronics, an additional data plate on the flowtube junction box (see

Figure 16) shows the Model Code and electrical safety data. For interpretation of the Model Code, refer to PL 008-714 for Style A and PL 008-753 for Style B.

Electrical certification information is located on the right end of the data plate.

The software version of your device can be found in View mode as 2 SW Rev.

Figure 15. Sample Flowmeter Data Plate





Figure 16. Sample Junction Box Data Plate



## Mechanical Installation

Both the flanged and wafer body flowmeters are offered in two mounting arrangements: (1) integral, and (2) remote (electronics housing separate from the flowmeter body). The following sections deal with both the integrally and remotely mounted electronics flowmeter arrangements. The installation guidelines given below are also summarized for your convenience in B0800AJ, *Ensuring Premium Performance with Foxboro 84 Series Intelligent Vortex Flowmeters*.

## Dimensions

For overall dimensions of the flowmeter, refer to the appropriate dimensional print listed in "Reference Documents" on page 13.

# Hydrostatic Piping Testing

The 84F Series Vortex Flowmeter is designed to meet the pressure limits of the flange rating specified in the model code.

84F-\*\*\*\*X

If your flowmeter is being installed in an application where hydrostatic testing will be performed, do **not** remove the sensor from the flowmeter.

# **Piping Considerations**

### Effects of Piping on Flowmeter Performance

### Flanges

The flange of the adjoining pipe must be the same nominal size and pressure rating as the flowmeter. Flanges with a smooth bore, similar to weld neck flanges, are preferred.

### **Mating Pipe**

Your flowmeter was calibrated at the factory with Schedule 40 piping upstream and downstream of the meter. If your application does not have Schedule 40 pipe, enter the appropriate pipe size during configuration. This assures that the calibration factor and flowmeter accuracy are maintained.

High-pressure meters (Class 900 and PN160 for 6- and 8-inch line sizes and Class 1500 for line sizes greater than 2 inches) were calibrated using Schedule 160 because the meter bore is also Schedule 160.

### Upstream and Downstream Disturbances

The flowmeter should normally be mounted in a straight, unobstructed pipe with a minimum of 30 pipe diameters upstream of the meter and five pipe diameters downstream. For those

installations where this upstream requirement is not met, the type of disturbance must be selected from a picklist during configuration and the distance to the disturbance in pipe diameters entered. This assures that the flowmeter accuracy is maintained.

#### **Piping Alignment**

The bore of the pipe (flange) and flowmeter must be aligned (see "Mechanically Installing the Flowmeter Body" on page 41), and the flange gaskets installed such that they do not protrude into the flow stream.

If the adjoining piping cannot be properly aligned, it is preferable to make the best possible alignment with the upstream flange. This minimizes the flow disturbance in the flowmeter.

#### - NOTE

- 1. Flowmeters mounted near pump discharge or suction lines may be exposed to oscillatory flow that may affect vortex shedding or product pipe vibration. Also, flowmeters mounted near the discharge of a liquid positive displacement pump or near oscillating control valves may experience severe flow fluctuations that could damage the sensor. To avoid these adverse situations, install the meter at least 20 feet or 40 pipe diameters, whichever is larger, from the disturbance in question.
- 2. Good piping practice requires that the internal surface of the pipe shall be free from mill scale, pits, holes, reaming scores, rifling, bumps, or other irregularities for at least four pipe diameters upstream and two pipe diameters downstream of the meter.

#### **Process Temperature**

Your flowmeter was calibrated at 70°F (21°C). If your process temperature is different, enter the appropriate process operating temperature during configuration. Your flowmeter automatically adjusts the calibration factor to account for thermal expansion of the metals due to process temperatures that are different than the reference calibration temperature.

#### **Pipe Position**

Piping should be planned to maintain full pipe conditions at the flowmeter. When flow is moving with gravity, elevate the downstream pipe length above the meter installation level to maintain a full pipeline.

#### **Mounting Position**


For optimal performance, the mounting locations of the sensor and integral electronics relative to the piping must be considered. Factors that influence this decision include process fluid type, ambient temperature, and vibration. Mount the meter in accordance with the installation guidelines for various process fluids described below. Also see Table 4.

### Liquid Installations

For liquid flow installations, it is recommended that the meter be mounted upstream at least 5 pipe diameters from the control valve. In vertical installations, the meter should be mounted in

the upward flowing leg. This helps to maintain a full pipe and ensures that there is sufficient back pressure to prevent flashing or cavitation.

For liquid installations with occasional gas pockets or bubble formation, install piping as recommended in Figure 17 so as to not trap the gas pockets or bubbles inside the flowmeter.



For a clean liquid, the electronics housing can be mounted above or below the flowmeter body. Care should be taken so that entrapped air does not accumulate in the sensor cavity. A meter used on liquid should be mounted upstream from a control valve. Flowmeters can also be mounted with the electronics housing positioned to the side. This ensures escape of entrapped air.

### Gas Installations


For gas flow installations, several choices for flowmeter location should be considered. For maximum rangeability, locate the flowmeter 30 or more pipe diameters downstream from a control valve. This ensures maximum velocity at the flowmeter and produces the most efficient signal from the sensor. This is especially recommended when several flowmeters/control valves are coming off a common header or pipe.

When the flow is more stable, the flowmeter can be mounted a minimum of 5 pipe diameters upstream of the control valve. Pressure fluctuations often are lower on the upstream side of a control valve flow than on the downstream side. This is recommended when a pressure sensor is used with a flowmeter to provide inputs to a flow computer.

On gas flow installations, avoid piping conditions that create standing pockets of liquids inside the meter. The best approach is to install the meter in a vertical line with flow in the upwards direction.

#### 

For condensate gas applications, take precautions to avoid any trapped condensate that can cause a "water hammer" during startup. If condensate cannot be drained, open the valve slowly, allowing any trapped condensate to travel downstream through the flowmeter at low velocity so that no damage occurs.



When the process fluid is gas, the electronics housing can be above or below the flowmeter body. The normal recommended position of the electronics housing is above the flowmeter body.

### Steam Installations


For steam control installations, it is recommended that the flowmeter be mounted 30 pipe diameters or more downstream of the **control** valve. This is particularly useful when measuring saturated steam to ensure that a minimum amount of condensate is present at the flowmeter.


### 

Take precautions to avoid any trapped condensate that can cause a "water hammer" during startup. If condensate cannot be drained, open the valve slowly, allowing any trapped condensate to travel downstream through the flowmeter at low velocity so that no damage occurs.

### Saturated Steam

When the process fluid is saturated steam, the electronics housing should be below the flowmeter body, so that the sensor cavity remains filled when condensate is present. Filling the sensor cavity with condensate results in a less noisy measurement caused by any flashing occurring in the flowmeter due to pressure drop.






## Superheated Steam

When the process fluid is superheated steam, the electronics housing may be above or below the flowmeter body. The flowmeter should be insulated to maintain superheat conditions inside the flowmeter as well as insulating the electronics from heat. Assure that the electronics temperature does not exceed 80°C (176°F) under all flow and environmental conditions.

## Insulation

The flowtube may be insulated up to the interface between the bonnet pad and the bonnet. No insulation is allowed beyond the bonnet pad. It is particularly important to insulate the flowtube on applications for superheated steam.



## Vibration

The vortex shedder axis should be oriented to reduce or, in some cases, virtually eliminate vibration influence. Position the flowmeter so that the sensor axis is perpendicular to the direction of the vibration. See Figure 21.




Figure 21. Sensor Mounting to Minimize Effect of Vibration

## Ambient Temperature Limitations / Considerations

The temperature limits of the electronics housing is -40 to +80°C (-40°F to +176°F). When installing the flowmeter, ambient temperature and proximity to other heat sources must be considered. For extended high temperature applications, this may require positioning the electronics housing to the side or bottom and/or piping insulation to assure the temperature limit is not exceeded. The maximum temperature rating of 80°C is an electrical safety agency requirement for all FM, CSA, IECEx, and ATEX certifications.

In installations where these agency certifications do not apply and ambient temperature limitations are not achievable, remotely mounting the electronics away from the process piping (to a lower temperature area) is recommended. In this configuration, only the preamplifier is in close proximity to the flowmeter and the preamplifier is rated for a maximum temperature of 105°C (221°F).

Flowmeter Orientation for Single (Shown) or Dual Measurement Flowmeter		Liquid	Gas	Saturated Steam	Superheated Steam
	Housing above and Isolation valve is not used	Yes (1)	Yes	No	Yes (2)
	Housing above and isolation valve is used	No (5)	Yes	No	Yes (2)

Table 4. Mounting Arrangements

Flowmeter Orientation for Single (Shown) or Dual Measurement Flowmeter			Gas	Saturated Steam	Superheated Steam
	Housing below pipe	Yes (3, 4, 6)	Yes (4)	Yes	Yes (2)
	Housing to side of pipe	Yes	Yes	No	Yes (2)
	Housing to side and below pipe	Yes (6)	Yes	No	Yes (2)
	Vertical pipe, flow upward	Yes	Yes	No	Yes (2)
	Vertical pipe, flow downward	Yes (7)	Yes	No	Yes (2)

#### Table 4. Mounting Arrangements

(1) Possibility of temporary startup error due to trapped air.

(2) Requires adequate insulation.

(3) Best choice when errors due to startup can not be tolerated.

(4) Recommended only for clean fluids.

(5) Not recommended for liquids with isolation valve.


(6) Preferred for liquids with isolation valve.

(7) Not preferred; must maintain full pipe with no voids in fluid.

## Meter Servicing

When you install the meter, consider meter repair. The meter should be accessible for servicing. For installations where the flow cannot be interrupted, depressurized, or drained, a flowmeter with an isolation valve is required.

Common practice is to install bypass piping so that the entire meter can be removed for servicing (see Figure 22).




## Location of Pressure and Temperature Taps

For pressure and/or temperature compensated flow measurement applications, locate the pressure and temperature taps as follows:

- NOTE The inside of the pipe at the pressure and temperature taps must be free of burrs and obstructions.

**Pressure Taps** -- For density measurement (when required), locate the tap 3-1/2 to 4-1/2 pipe diameters **downstream** of the flowmeter. See Figure 23.



### Figure 23. Pressure and Temperature Tap Locations

#### - NOTE

- 1. On a gas flow installation, the pressure tap should be located on the top of the pipe.
- 2. On a liquid installation, the pressure tap (if required) should be located on the side of the pipe.
- 3. On a steam installation, the pressure tap should be located on the top when the pressure measuring device (typically a pressure transmitter) is above the pipeline, and on the side when the measuring device is below the pipeline.
- 4. With vertical piping, the pressure tap can be located anywhere around the circumference of the pipeline.

**Temperature Taps** -- For temperature measurement (when required), locate the tap 5 to 6 pipe diameters **downstream** of the flowmeter. To reduce flow disturbance, use the smallest possible probe. See Figure 23.

## Mechanically Installing the Flowmeter Body

#### - NOTE

If the electronics are mounted remotely, mount the flowmeter body so that the junction box is serviceable.

## 84F – Flanged Body

- 1. Gaskets are required and must be supplied by the user. Select a gasket material suitable for the process.
- 2. Insert gaskets between the body of the flowmeter and adjacent flanges. See Figure 24. Position the gaskets so that the ID of each gasket is centered on the ID of the flowmeter and adjacent piping.

### 


Verify that the ID of the gaskets is larger than that of the flowtube bore and pipe and that the gaskets do not protrude into the flowtube entrance or exit. Protrusion into the flowstream has an adverse effect on performance.


### 

Gaskets do not prevent flanges from being wetted by process fluids.

#### - NOTE

When you install new flanges in the process piping and use the meter as a gauge to set the flanges, protect the inside diameter of the flowmeter from weld splatter. Install a solid sheet of gasketing at each end of the meter during welding. Remove this sheet and install the flange gaskets after welding. Remove any splatter in either the pipe or the meter as it could affect flowmeter accuracy.





- 3. Visually inspect for concentricity (centering and alignment) of mating flanges.
- 4. Tighten bolts in accordance with conventional flange bolt tightening practice (that is, incremental and alternate tightening of bolts).

## 84W – Wafer Body

For optimal performance, the wafer body flowmeter should be centered with respect to the adjoining pipe. Normally, this requires the use of centering fixtures that are supplied with the meter.

#### 

Centering fixtures are not required for meters with ANSI Class 150 flanges.

- 1. See Figure 25. Insert the first stud through the downstream flange at one of the lower holes, through the two hex-nut spacers, and then through the upstream flange. Place the nuts on both ends of the stud, but do not tighten.
- 2. Using the remaining hex-nut spacers, repeat Step 1 at the lower hole adjacent to the first.
- 3. Set the flowmeter between the flanges. Then, rotate spacers to the thickness that centers the meter.

#### - NOTE -

By rotating the hex-nut spacers to the correct thickness, you can center the meter to any type of flange.

- 4. Gaskets are required and must be supplied by the user. Select a gasket material suitable for the process fluid.
- 5. Insert gaskets between the body of the flowmeter and adjacent flanges. Position the gaskets so that the ID of each gasket is centered on the ID of the flowmeter and adjacent piping.

### - ! CAUTION

Verify that the ID of the gaskets is larger than that of the flowtube bore and pipe and that the gaskets do not protrude into the meter entrance or exit. Protrusion into the flowstream has an adverse effect on performance.

#### - NOTE

If welding the flanges to the process piping is required, protect the flowmeter from weld splatter, which could affect flowmeter accuracy. A solid sheet of gasketing should be installed at each end of the meter during welding. Remove this sheet and install the flange gaskets after welding.

- 6. Visually inspect for concentricity (centering and alignment) of mating flanges.
- 7. Install the rest of the studs and nuts and tighten the nuts in accordance with conventional flange bolt tightening practice (that is, incremental and alternate tightening of bolts).

#### - NOTE

If the adjoining flanges are misaligned, align the wafer body flowmeter with the **upstream** flange.





Figure 25. 84W Flowmeter Centering (using Spacers)



## Threaded (MNPT)

- 1. Apply process compatible thread sealant to the threaded flowtube end connection.
- 2. Secure the threaded pipe adapter to the flowtube threaded end connection.
- 3. Secure the pipeline end of adapter to the pipeline.

## Mounting the Remote Electronics Housing

The purpose of the remote electronics housing is to allow for separation of the flowmeter body and the electronics.

A flowmeter with remote electronics consists of:

- An electronics housing mounted to a pipe or wall mounting bracket with up to 15 m (50 ft) of interconnecting cable attached.
- A flowmeter body with junction box.


1/2 NPT or M20 conduit connections are provided on both the housing and the junction box.

The remote electronics housing can be mounted to a vertical or horizontal DN 50 or 2-in pipe using the mounting bracket and U-bolt supplied. To mount the housing to a horizontal pipe, turn the U-bolt 90 degrees from the position shown in Figure 26.

The housing can be surface mounted by securing the mounting bracket to a wall using the bracket mounting holes. It may be easier to secure the mounting bracket to the wall without the housing attached. To do this, use the following procedure:

- 1. Remove the jam nut under the bracket.
- 2. Raise the housing until you can slide the cable through the cutout in the bracket.
- 3. Lay the housing aside and secure the mounting bracket to the wall.
- 4. Reverse Steps 2 and 1.


### Figure 26. Mounting the Remote Electronics Housing



## Cover Locks

Electronic housing cover locks, shown in Figure 27, are provided as standard with certain agency certifications. To lock the covers, unscrew the locking pin until approximately 6 mm (0.25 in) shows, lining up the hole in the pin with the hole in the housing. Insert the seal wire through the two holes, slide the seal onto the wire ends and crimp the seal.

#### Figure 27. Cover Locks



## Positioning the Display

The display (optional in some models) can be rotated within the housing to any of four positions at 90° increments. To do this, loosen the two captive screws, turn the display to the desired position, and retighten the screws.


### - CAUTION


1. Do **not** turn the display more than 180° in any direction. Doing so could damage its connecting cable.

2. Carefully fold the ribbon cable in the space between display and the electronic module so that it is not pinched. The display molding should rest firmly against the module molding before tightening the screws.

## Setting the Write Protect Jumper

Your transmitter has write protection capability which meets the security requirements of ISA-S84.01-1986 for use in safety shutdown systems. This means that the local display and remote electronics can be prevented from writing to the electronics. Write protection is set by moving a jumper that is located in the electronics compartment behind the display. To activate write protection, remove the display and remove the jumper or place it in the 'protect' position. In the 'write' position, writing to certain functions can be limited by password protection. See "Password" on page 60.






## Positioning the Housing

The flowmeter housing (topworks) can be rotated up to one full turn in the counterclockwise direction when viewed from above for optimum access to adjustments, display, or conduit connections. Housings have either an anti-rotation screw or a retention clip that prevent the housing from being rotated beyond a safe depth of housing/sensor thread engagement.

#### Figure 29. Housing Screw or Clip Location



## **Electrical Installation**

This section describes procedures for installing wiring, conduit, and ground connections for both integral and remote mounted flowmeters and for preparing remote signal cables for interconnection.

#### 

The transmitter housing must be grounded to insure proper operation and peak performance.

#### 

The wiring installation must be in accordance with local or national regulations applicable to the specific site and classification of the area.

## **Integrally Mounted Electronics**

A flowmeter with a integrally mounted electronics requires only power and output signal wiring. To complete installation, refer to "Field Termination Wiring" on page 49.

## **Remotely Mounted Electronics**

To use the flowmeter as shipped with the cable attached at both ends, mount the electronics housing and flowmeter body within the limits of the cable length.

If the cable must be disconnected (to shorten the cable, run the cable through conduit, or for some other reason), you **must** disconnect the cable at the flowmeter (junction box) end. You cannot disconnect the cable at the electronics housing end because it has been epoxied into the metal connector. It is labeled "Factory Sealed / Electronics End / Do Not Remove."


## Preparing the Remote Signal Cable

If the cable must be shortened or reterminated, the flowmeter (junction box) end of the cable must be prepared per the instructions in Table 5.

1100 9. 1 reputation 6	J Remote Signal Cable (Junction Dox Ena)
1. Insert the cable into the knurled nut and rubber grommet. Then remove the outer insulation to the dimen- sion shown. Do not damage the copper braid.	8.5±1/8"
2. Cut the copper braid 1 inch from the end of the outer insulation.	Copper braid Outer Clear wrapping
3. Insert the cable into the fitting until the cable is bottomed out inside the fitting. Rotate the fitting one or two turns to pack the braid into place. Remove the cable and examine the packed braid. If there are still strands of braid that have not packed, push them back by hand and reinsert the cable into the fit- ting. Remove the cable and examine the braid. It should be compressed to a length of approximately 3/8 to 1/2 inch.	Compressed copper braid Fitting Correct Rubber grommet Note: Fitting is connected to junction box (not shown)
4. Remove the outer clear wrapping and the metalized mylar film to the end of the packed braid. This exposes the inner drain wire. The inner clear wrapping and filler mate- rial are still in place.	3/8" to 1/2" Outer Clear → wrapping
5. Make sure that the drain wire is not in contact with the outer braid. Then use an ohm meter to verify that there is no electrical connection between the drain wire and the braid over the entire length of the cable. This step also verifies that the other end (electronics end) of the cable has been properly dressed and that there is no damage or defects in the cable.	Metalized mylar film Drain wire Inner Clear wrapping

### Table 5. Preparation of Remote Signal Cable (Junction Box End)





## Connecting the Remote Signal Cable

After the cable end has been prepared, connect the cable to the junction box. See Figure 30.

- 1. Insert the cable into the fitting, making sure that the cable has bottomed out in the fitting.
- 2. Slide the rubber grommet into the fitting.
- 3. Screw the knurled nut into place, clamping the rubber grommet against the assembly. Hand tighten with moderate force to assure a water tight connection.
- 4. Dress the wires in the junction box as shown.




Figure 30. Connection of Remote Signal Cable (Junction Box End)

## Installation with Conduit

The remote signal cable is shipped with the cable attached at both ends. To run the cable through conduit, the -T option must have been purchased. This option facilitates a standard 1/2 NPT conduit connection at both the housing end and the flowmeter end.

- 1. Disconnect the cable at the flowmeter (junction box) end.
- 2. Slide the remote conduit adapter (part number K0149LE), longer end first, up the cable and attach it at the housing end.
- 3. Slide the conduit and fittings over the cable.
- 4. Slide a second remote conduit adapter, shorter end first, onto the cable and attach it at the junction box end.

## Explosionproof / Flameproof Certifications

The remote cable provides an explosionproof / flameproof connection at the electronics end. Explosionproof connections beyond this point are not required.

## Field Termination Wiring

The installation and wiring of your flowmeter must conform to local code requirements. Also, for FM installations, refer to MI 019-177; for ATEX and IECEx installations, refer to MI 019-179.

#### - NOTE

Invensys recommends the use of transient/surge protection in installations prone to high levels of electrical transients and surges.


## Conduit / Cable Gland Connections


The electronics housing has two conduit/cable gland connections to allow access from either side of the housing. These connections are 1/2 NPT or M20 threads per your order. Make sure to use the correct threaded devices when making these connections. The type of thread can be verified by viewing the eighth character after the dash in the model code on the data plate. The letters T or R indicate a 1/2 NPT thread; V or W, an M20 thread.

The housing comes with a safety-agency approved threaded metal plug in one of the conduit holes and a plastic plug in the other. After the conduit or cable gland is connected, plug the unused hole with the metal plug. To maintain specified explosionproof and dust-ignitionproof protection, plug must be engaged a minimum of five full threads for 1/2 NPT connections; seven full threads for M20 connections.

## Accessing Flowmeter Field Terminals


For access to the field terminals, remove the cover from the field terminals compartment as shown in Figure 31. Note that the embossed letters FIELD TERMINALS identify the proper compartment.





When wiring a flowmeter with 4 to 20 mA output signal, the supply voltage and loop load must be within specified limits. The supply output load vs. voltage relationship is shown in Figure 33.

Any combination of supply voltage and loop load resistance in the shaded area can be used. To determine the loop load resistance (flowmeter output load), add the series resistance of each component in the loop, excluding the flowmeter. The power supply must be capable of supplying 22 mA of loop current.



NOTE:

THE FLOWMETER FUNCTIONS WITH AN OUTPUT LOAD LESS THAN 250  $\Omega$  PROVIDED THAT A PC-BASED CONFIGURATOR OR HART COMMUNICATOR IS NOT CONNECTED TO IT. CONNECTING A PC-BASED CONFIGURATOR OR HART COMMUNICATOR WHILE OPERATING BELOW A 250  $\Omega$  LOAD MAY CAUSE OUTPUT DISTURBANCE AND/OR COMMUNICATION PROBLEMS.

### **Examples:**

- 1. For a loop load resistance of 300  $\Omega,$  the supply voltage can be any value from 19.1 to 30 V dc.
- 2. For a supply voltage of 24 V dc, the loop load resistance can be any value from 250 to 520  $\Omega$  (zero to 520  $\Omega$  without a HART Communicator or PC-Based Configurator connected to the flowmeter).

To wire one or more flowmeters to a power supply, proceed with the following steps.

- 1. Remove the cover from the field terminals compartment.
- 2. Run signal wires (0.50 mm<sup>2</sup> or 20 AWG, typical) through one of the flowmeter conduit connections. Use twisted pair to protect the 4 to 20 mA output and/or remote communications from electrical noise. Maximum recommended length for signal wires is 1800 m (6000 ft)


— NOTE -

Do not run flowmeter wires in same conduit as mains (ac power) wires.

- 3. If shielded cable is used, ground the shield at the negative terminal of the power supply. Do **not** ground the shield at the flowmeter.
- 4. Plug the unused conduit opening with the 1/2 NPT or M20 metal plug provided (or equivalent). To maintain specified explosionproof and dust-ignitionproof protection, plug must be engaged a minimum of five full threads for 1/2 NPT connections; seven full threads for M20 connections.
- 5. The flowmeter is equipped with an internal and external ground connection. Connect a ground wire to either terminal in accordance with local practice.

If the loop is grounded, it is preferable to do so at the negative terminal of the dc power supply. To avoid errors resulting from earth loops or the possibility of short-circuiting groups of instruments in a loop, there should be only one earth in a loop.

- 6. Connect the power supply and receiver loop wires to the "+" and "-" terminal connections.
- 7. Connect receivers (such as controllers, recorders, indicators) in series with power supply and flowmeter as shown in Figure 34.
- 8. Install the cover onto the flowmeter. Turn the cover to seat the O-Ring into the housing and continue to hand tighten until the cover contacts the housing metal-to-metal. If cover locks are present, refer to "Cover Locks" on page 44.
- 9. If wiring additional flowmeters to the same power supply, repeat Steps 1 through 8 for each additional flowmeter.
- 10. A HART Communicator or PC-based Configurator can be connected in the loop between the flowmeter and the power supply as shown in Figure 34. Note that a minimum of 250  $\Omega$  must separate the power supply from the HART Communicator or PC-Based Configurator.



#### Figure 34. Loop Wiring 4 to 20 mA Output Flowmeters

(e) REQUIRED FOR EXPLOSIONPROOF (FLAMEPROOF) APPLICATIONS.


## Multidrop Communication

"Multidropping" refers to the connection of several flowmeters to a single communications transmission line. Communications between the host computer and the flowmeters takes place digitally with the analog output of the flowmeter deactivated. With the HART communications protocol, up to 15 flowmeters can be connected on a single twisted pair of wires or over leased telephone lines.

The application of a multidrop installation requires consideration of the update rate necessary from each flowmeter, the combination of flowmeter models, and the length of the transmission line. Multidrop installations are not recommended where Intrinsic Safety is a requirement. Communication with the flowmeters can be accomplished with any HART compatible modem and a host implementing the HART protocol. Each flowmeter is identified by a unique address (1-15) and responds to the commands defined in the HART protocol.

Figure 35 shows a typical multidrop network. Do not use this figure as an installation diagram. Contact the HART Communications Foundation, (512) 794-0369, with specific requirements for multidrop applications.






The HART Communicator can operate, configure, and calibrate 84 Series Flowmeters with HART communication protocol in the same way as it can in a standard point-to-point installation.

#### - NOTE -

84 Series Flowmeters with HART communication protocol are set to poll address 0 (POLLADR 0) at the factory, allowing them to operate in the standard point-to-point manner with a 4 to 20 mA output signal. To activate multidrop communication, the flowmeter address must be changed to a number from 1 to 15. Each flowmeter must be assigned a unique number on each multidrop network. This change deactivates the 4 to 20 mA analog output.

## Wiring a Flowmeter With a Pulse Output

Two separate loops are required when using the pulse output on an 84F-T (Styles A and B) or 84W-T Flowmeter with the 4 to 20 mA or digital signal. Each loop requires its own power supply. Figure 36 shows the connections with a transistor switch (sinking) counter input with receiver supplied power; Figure 37, with a transistor switch (sinking) counter input and external power supply and pull-up resistor; and Figure 38 with a transistor switch (sourcing) counter input and external power supply and pull-up resistor.







Figure 37. Wiring an 84F-T (Styles A and B) or 84W-T Flowmeter with a Pulse Output Transistor Switch (sinking) Counter Input with External Power Supply and Pull-Up Resistor



(a) GROUNDING THE LOOP AT THE NEGATIVE TERMINAL OF THE POWER SUPPLY IS RECOMMENDED BUT NOT REQUIRED.

(b) IF SHIELDED WIRE IS USED, TERMINATE THE SHIELD AT THE NEGATIVE TERMINAL OF THE POWER SUPPLY.

(c) THE TRANSMITTER IS EQUIPPED WITH AN INTERNAL AND EXTERNAL GROUND CONNECTION.

- CONNECT A GROUND WIRE TO EITHER TERMINAL IN ACCORDANCE WITH LOCAL PRACTICE. (d) THERE MUST BE AT LEAST 250 W TOTAL RESISTANCE BETWEEN THE PC-BASED CONFIGURATOR
- OR THE HART COMMUNICATOR AND THE POWER SUPPLY.
- (e) MAXIMUM PULSE OUTPUT CURRENTIS 20 mA. LOAD RESISTOR MUST BE SIZED ACCORDINGLY.
- (f) REQUIRED FOR EXPLOSIONPROOF (FLAMEPROOF) APPLICATIONS.




Figure 38. Wiring an 84F-T (Styles A and B) or 84W-T Flowmeter with a Pulse Output Transistor Switch (sourcing) Counter Input with External Power Supply and Pull-Up Resistor

## Wiring a Flowmeter with a Pulse Output (3-Wire)

This wiring method is primarily used when using a Model 84 Transmitter to replace an E83FA, E83WA, or Model 83 Transmitter that was wired using a 3-Wire hookup.

For new installations, a 4-Wire hook-up is recommended because the 3-Wire hookup method can interfere with HART communications at certain pulse output frequencies.




Figure 39. Wiring an 84F-T (Styles A and B) or 84W-T Flowmeter with a Pulse Output Using a 3-Wire Hookup

(a) PLACE JUMPER BETWEEN THE TWO NEGATIVE TERMINALS AS SHOWN.

(b) ADD A 1200 OHM MINIMUM (1-2 WATT) RESISTOR BETWEEN POWER SUPPLY (+) AND COUNTER (+).

(c) GROUNDING THE LOOP AT THE NEGATIVE TERMINAL OF THE POWER SUPPLY IS RECOMMENDED BUT NOT REQUIRED.

(d) THE TRANSMITTER IS EQUIPPED WITH AN INTERNAL AND EXTERNAL GROUND CONNECTION. CONNECT A GROUND WIRE TO EITHER TERMINAL IN ACCORDANCE WITH LOCAL PRACTICE.

(e) THERE MUST BE AT LEAST 250 W TOTAL RESISTANCE BETWEEN THE PC-BASED CONFIGURATOR OR THE HART COMMUNICATOR AND THE POWER SUPPLY.

(f) REQUIRED FOR EXPLOSIONPROOF (FLAMEPROOF) APPLICATIONS.

# 3. Operation Via Local Display


Communication with the 84F-T (Styles A and B), 84F-U (Styles A and B), 84W-T, and 84W-U Vortex Flowmeters is carried out using the HART Communicator, a PC-Based configurator, or the optional Local Keypad/Display. General instructions for using the HART Communicator can be found in MAN 4250, HART Communicator Product Manual. Instructions for using the HART Communicator with an 84 Series flowmeter is located in Section 4 of this document. Instructions for using the PC-Based configurator are included with the configurator software. Instructions for using the Local Keypad/Display is found in this section.

#### - NOTE

For proper communication with a HART Communicator, the communicator must contain the proper DD for the 84 Vortex Flowmeter. This DD is available from Invensys or any other authorized HART Foundation source.

## Local Keypad/Display

A local display, as shown in Figure 40 provides local indication of the measurement information, function status, and reference information. The display also provides a means of performing totalizer reset, and full configuration, calibration, and self-test. Operation is accomplished via four multi-function keys.



Function
Moves left in the menu structure. Moves the cursor to the left in a data entry field. Escapes from changes in a picklist menu or data entry.* Answers No.
Moves right in the menu structure. Used to access the data entry edit mode of a parameter. Moves the cursor to the right in a data entry field. Enters and saves the changed menu picklist choices or data entry.* Answers Yes.
Moves upward in the menu structure, a picklist menu, or list of characters.
Moves downward in the menu structure, a picklist menu, or list of characters.

Table 6.	Operation	of Function K	Leys
----------	-----------	---------------	------

\*On data entry, repeatedly press the key until the cursor reaches the end of the display.

## **Display Bar Indicator**

The bar indicator at the top of the display indicates the flow measurement, as a percentage of the upper range value.

- NOTE -

If the flow measurement is out-of-range, the bar indicator blinks. If the flowmeter is off-line, the middle four bars of the bar indicator blink.

## Password

Display of information requires no password. However, the ability to access certain functions, (for purposes other than Read Only), such as totalizer, setup, and calibration/testing, may require a user-definable password. The LOPwd allows you to reset the Net Totalizer and Pulse Totalizer. The HiPwd gives you access to all flowmeter functions. In addition, the write protect jumper must be in the 'write' position. See "Setting the Write Protect Jumper" on page 45.

#### - NOTE

The flowmeter is shipped from the factory with a blank password. This allows access to all flowmeter functions. If password protection is required, enter a LOPwd and/or HiPwd in Setup mode.

## Entering the Password

The totalizer, setup, and calibration/test functions may require a password (a 4-character alphanumeric string). Select the TotPul, TotNet, TotGrd, Setup or Cal/Tst top level menu and press Enter at the password prompt. Two brackets surrounding four spaces ([\_\_\_\_]) then appear on the second line of the display. The cursor, a flashing icon, appears at the first character.

To enter the password, use the Up/Down arrow keys to scroll through the list of acceptable characters. After selecting the desired character, press the Right arrow key to move to the next character. Continue this process until the password is complete. Pressing the Right arrow key once

more moves the flashing cursor to the right bracket. Pressing Enter now completes the process. Prior to pressing Enter, you can use the Left/Right arrow keys to move back and forth to modify an incorrect selection.

If you enter an incorrect password, the display indicates **Sorry** for one second, then goes to Read Only.

You can change a password in the Passwd parameter in the Setup menu.

## Activating an Edit, Pick-List, or User Menu Block

To open a menu block that allows you to edit or select data or to perform a function, move to the menu block and press the Right arrow (Enter) key.

## Editing Numbers and Strings

Editing any number or string in the menu system is done in the same way as entering the password. The Up/Down arrow keys scroll through a list of acceptable characters for the current position. The Right arrow key moves the cursor to the right. It also accepts the change at the end. The Left arrow key moves the cursor to the left. It also cancels the change at the beginning.

There are three kinds of edit items: signed numbers, unsigned numbers, and strings.

### Signed Numbers

Signed numbers always have a + or - sign at the beginning. The + can only be changed to -, and vice versa.

### Unsigned Numbers

For unsigned numbers, cycle through the digits 0-9, and the decimal point, with the Up/Down arrow keys. When you enter a decimal point in any position, and there is already a decimal point to the left of the cursor, the new decimal point overrides the old one.

### Strings

Characters in strings can be changed to any valid character. You can sequence through the list of characters by pressing the Up/Down arrow keys. To enter the change, you must still press Enter from the right side of the data field, after scrolling to the right with the Right arrow key.

## Picking from a List

Picklist items allow you to choose a selection from a flowmeter-supplied list of alternatives. Go to the applicable parameter, and press Enter. The entire bottom line of the display flashes. If you press the Up/Down arrow keys, the display shows the previous or next choice respectively from its list. Pressing Enter accepts the change; pressing Esc returns the previous selection.

## Configuration Database

Each flowmeter is shipped from the factory with an operating configuration database. However, the flowmeter will not provide an accurate measurement if the configuration does not fit your application. Be sure to check the configuration of our flowmeter prior to start-up.

If the user information is not supplied with the purchase order, the flowmeter is shipped with the following defaults:

Item	Metric	English
Fluid Type	Liquid (water)	Liquid (water)
Type of Flow	Volume	Volume
Measurement Units	m <sup>3</sup> /s	gal/min
Flowing Temperature	20°C	68°F
Flowing Density	998.21 kg/m <sup>3</sup>	62.316 lb/ft <sup>3</sup>
Absolute Viscosity	1.002 cP	1.002 cP
Upper Range Value	Upper Range Limit for Flowmeter Size	Upper Range Limit for Flowmeter Size

Table 7. Default Database When User Information Not Supplied

These defaults are **not** recommended for general operation. If no other process information is available, entering Liquid, Gas, or Steam as fluid type in Setup > Fluid > New establishes default data bases as shown in Table 8, 9, or 10 respectively.

Parameter	Metric	English	
Fluid Type	Liquid (water)	Liquid (water)	
Type of Flow	Same as present configuration		
Measurement Units	Same as present configuration		
Flowing Temperature	20°C	68°F	
Flowing Density	998.21 kg/m <sup>3</sup>	62.316 lb/ft <sup>3</sup>	
Absolute Viscosity	1.002 cP	1.002 cP	
Upper Range Value	Upper Range Limit for Flowmeter Size	Upper Range Limit for Flowmeter Size	

Table 8. Default Database for Liquid

Table 9. Default Database for Gas

Parameter	Metric	English	
Fluid Type	Gas (air)	Gas (air)	
Type of Flow	Same as present configuration		
Measurement Units	Same as present configuration*		
Flowing Temperature	20°C	68°F	
Flowing Density	9.546 kg/m <sup>3</sup>	0.596 lb/ft <sup>3</sup>	
Absolute Viscosity	0.0185 cP	0.0185 cP	
Upper Range Value	Upper Range Limit for Flowmeter Size	Upper Range Limit for Flowmeter Size	

\*Liquid units of gallons, liters, imperial gallons, or barrels per unit time are not transferable to gas.

Parameter	Metric	English	
Fluid Type	Steam	Steam	
Type of Flow	Same as present configuration		
Measurement Units	Same as present configuration*		
Flowing Temperature	178.3℃	352.9°F	
Flowing Density	4.966 kg/m <sup>3</sup>	0.310 lb/ft <sup>3</sup>	
Absolute Viscosity	0.015 cP	0.015 cP	
Upper Range Value	Upper Range Limit for Flowmeter Size	Upper Range Limit for Flowmeter Size	

Table 10. Default Database for Steam	Table 10.	Default	Database	for	Steam
--------------------------------------	-----------	---------	----------	-----	-------

\*Liquid units of gallons, liters, imperial gallons, or barrels per unit time are not transferable to steam.

## Using the Menu Tree

## Moving Inside the Menu System

Pressing the Enter key stops the display of measurements and shows the first top level Totalizer menu item, 1 TotPul. Use the Down arrow key to go to 1 TotNet and 1 Tot Grd. At any one of these choices, press Enter to edit your selection. Use the Down arrow key to select Off (turn the totalizer off), On (turn the totalizer on), or Clear (reset the totalizer) and then press Enter. Press the ESC key to return to Measure mode.

Pressing the Esc key stops the display of measurements, and shows the first item in the rest of the top level menu, 1 Measure. From here, the four keys allow you to move around the menu tree, as indicated by the arrows. Press the Down arrow key to cycle through each of the current menu level items. Press the Right arrow key to move from the current level to its submenu level. Press the Left arrow key to move from the current level to the next higher level.

## **Each** menu item has its level (1 - 5) displayed at the beginning of the top line.

## Top Level Menu

The three totalizer items in the main menu were discussed immediately above. The remainder of the Top Level menu displays six modes – Measure, Status, View, Setup, and Calibration/Test. You can switch from one to another in sequence by using the Up/Down arrow keys. To enter the second level menu from a particular top level display, press the Right arrow key. To return to the top level from a second level menu item, press the Left arrow key. The level of the first, second, third, fourth, and fifth level menus is indicated by the digit appearing as the first character in Line 1 of the display; a 1 indicates Level 1 (Top Level), a 2 indicates Level 2, and a 3 indicates Level 3, and so forth.

The top level menu is shown in Figure 41.




Figure 41. Top Level Modes and Their Basic Functions

(a) Not shown for option "U".

#### - NOTE

Certain parameters may be missing as you step through the menus described in this chapter depending on the configuration of your instrument.

## Measure Mode

In normal operation, the flowmeter displays those measurements specified in Setup mode. If configured for Manual cycle, you can cycle through the measurements manually by using the Up/Down arrow keys. If configured for Auto cycle, the display cycles through the measurements specified. If, while in Auto cycle, you want to see a specific measurement momentarily, advance to that measurement with the Down arrow key. Use the Up arrow key to go to a specific measurement and stay there. You can then resume scanning by pressing the Down arrow key.

## Totals Mode

TotPul, TotNet, or TotGrd is used to turn a totalizer on, pause the totalizer, or to clear (reset) the total. This is done by pressing the Enter key and selecting On, Paused, or Clear and pressing the Enter key again. Before doing this you may be asked for a password. If so, enter the LoPwd or HiPwd for TotPul and TotNet; enter the HiPwd for TotGrd.

## Status Mode

The MeaStat sublevel of this mode enables you to view the units, value, and status of system parameters and thus assess the performance of the loop. You can not edit them in this mode. To step through the displays of the parameters, use the Up/Down arrow keys. The Status mode structure diagram is shown in Figure 42.

The WrProt sublevel of this mode shows whether write protection is enabled (Prot) or is disabled (NotProt).

The DiagEr sublevel of this mode shows any diagnostic errors. The display 0000 means no diagnostic errors.

#### - NOTE

A new diagnostic condition only appears after a diagnostic is detected while in Measure mode.

I





Figure 42. Status Mode Structure Diagram

(a) Not available for "Low Power" Vortex flowmeters.

(b) Only available for "Low Power" options. Not available for "U".

## View Mode

The View mode enables you to view the identity parameters. You can not edit them in this mode. To step through the list of the following parameters, use the Up and Down arrow keys.



#### Figure 43. View Mode Structure Diagram

## Setup Mode

The Setup mode enables you to configure your flowmeter fluid, flow, tuning, totalizer, output, pipe, tag, flowtube, and password parameters. You can also establish and change your passwords in this mode.

Setup mode can be a passcode protected mode. So after the initial configuration, you may need to enter the HiPwd to make changes in this mode. See "Password" on page 60.

```
NOTE If you lose your password, call our Global Customer Support for assistance.
```

If your transmitter is write protected, the display reads Rd Only if you try to enter Setup mode. In this case, you cannot enter Setup mode to make changes. You can, however, view but not edit the setup.

Upon attempts to enter this mode, you are asked, Loop in Manual? After placing the loop in manual, indicate 'yes' with the Enter key. This is also an off-line mode. Analog output is driven to 4 mA, pulse to 0.

The structural diagrams for the Setup mode begin on page 76.

### Setting Fluid Parameters

The 2 Fluid section of the Setup mode allows you to configure parameters for fluid type, fluid name (optional), temperature unit, flow temperature, density unit, flow density, base density, viscosity unit, and viscosity.

#### - NOTE -

If you are satisfied with the existing fluid parameters, do **not** enter the **3** New parameter; doing so will reset all the other fluid parameters.

- In 3 New, select the fluid as Liquid, Gas, or Steam to get the default data base for that medium. Refer to Table 8, Table 9, and Table 10.
   Selecting 3 Edit enables you to edit the present fluid configuration.
- FldTyp shows the type of fluid presently configured.
- In 3 Name, name the particular fluid (optional).
- In 3 TmpEGU, select your choice of temperature unit (degF, degC, degR, or degK).
- In 3 FlwTmp, enter he flow temperature in the temperature unit specified.
- In 3 DenEGU select the density unit from the following picklist: kg/m3, lb/Yd3, lb/gal, oz/in3, lb/ft3, g/cm3, ST/Yd3, LT/Yd3, Custom.
   If you pick Custom, you must define your custom unit. First, enter a Label for your custom unit using up to eight alphanumeric characters. Then, enter any Offset and a conversion factor (Slope) from kilograms per cubic meter to the custom unit.
- In 3 FlwDen, enter the flow density in the density unit specified.
- In 3 BasDen, enter the base density in the density unit specified.
- LfciEGU shows the units of the low flow cut-in.
- Lfci shows the Lfci presently configured.
- In 3 VisEGU, select the viscosity unit (cPoise, Poise, cStoke, or PaSec).
- In 3 Visc, enter the viscosity in the viscosity unit specified.

The following table lists the engineering units (EGUs) available. The available EGU options depend on the FlwMap selection (VolFlow, BVolFlow, MassFlow, or Velocity), and the actual EGUs are entered in the 1 Setup > 2 Flow > 3 FlwEGU menu.

Fluid Type	FlwMap Selected	Available EGUs
Liquid	Volume (VolFlow)	m3/s, m3/m, m3/h, m3/d, gal/s, gal/m, gal/h, gal/d, Mgal/d, l/s, l/m, l/h, l/d, Ml/h, Ml/d, ft3/s, ft3/m, ft3/h, ft3/d, bbl3/s(31.5), bbl3/m, bbl3/h(31.5), bbl3/d, bbl/s, bbl/m, bbl/h, bbl/d, igal/s, igal/m, igal/h, igal/d, mcfd, mmcfd, Custom
	Base Volume, Standard (BVolFlow > StdVol)	Sm3/s, Sm3/m, Sm3/h, Sm3/d, Sft3/s, Sft3/m, Sft3/h, Sft3/d, Sgal/s, Sgal/m, Sgal/h, Sgal/d, Sbl3/s (31.5), Sbl3/m (31.5), Sbl3/h (31.5), Sbl3/d (31.5), Sbbl/s (42), Sbbl/m (42), Sbbl/h (42), Sbbl/d (42), mScfd, mmScfd, Custom
	Base Volume, Normal (BVolFlow > NormVol)	Ngal/s, Ngal/m, Ngal/h, Ngal/d, Nl/s, Nl/m, Nl/h, Nl/d, Nm3/s, Nm3/m, Nm3/h, Nm3/d, Custom
	Mass (MassFlow)	kg/s, kg/m, kg/h, kg/d, g/s, g/m, g/h, g/d, lb/s, lb/m, lb/h, lb/d, mton/h, mton/d, STon/s, STon/m, STon/h, STon/d, oz/s, oz/m, oz/h, oz/d, mton/s, mton/m, LTon/m, LTon/h, LTon/d, Custom
	Velocity	m/s, m/m, m/h, m/d, ft/s, ft/m, ft/h, ft/d
Gas	Volume (VolFlow)	ft3/s, ft3/m, ft3/h, ft3/d, m3/s, m3/m, m3/h, m3/d, mcfd, mmcfd, Custom
	Base Volume, Standard (BVolFlow > StdVol)	Sft3/s, Sft3/m, Sft3/h, Sft3/d, mScfd, mmScfd, Sm3/s, Sm3/m, Sm3/h, Sm3/d, Custom
	Base Volume, Normal (BVolFlow > NormVol)	Nm3/s, Nm3/m, Nm3/h, Nm3/d, Nl/s, Nl/m, Nl/h, Nl/d, Custom
	Mass (MassFlow)	lb/s, lb/m, lb/h, lb/d, kg/s, kg/m, kg/h, kg/d, g/s, g/m, g/h, g/d, mTon/s, mTon/m, mTon/h, mTon/d, STon/s, STon/m, STon/h, STon/d, LTon/m, LTon/h, LTon/d, oz/s, oz/m, oz/h, oz/d, Custom
	Velocity	ft/s, ft/m, ft/h, ft/d, m/s, m/m, m/h, m/d
Steam	Volume (VolFlow)	ft3/s, ft3/m, ft3/h, ft3/d, m3/s, m3/m, m3/h, m3/d, mcfd, mmcfd, Custom
	Mass (MassFlow)	lb/s, lb/m, lb/h, lb/d, kg/s, kg/m, kg/h, kg/d, g/s, g/m, g/h, g/d, mTon/s, mTon/m, mTon/h, mTon/d, STon/s, STon/m, STon/h, STon/d, LTon/m, LTon/h, LTon/d, oz/s, oz/m, oz/h, oz/d, Custom
	Velocity	ft/s, ft/m, ft/h, ft/d, m/s, m/m, m/h, m/d

### Table 12. All Flow EGU Descriptions (Volume, Mass, Base Volume, and Velocity)

EGU	Description	EGU	Description	EGU	Description
lb/ft3	pounds per cubic foot	LTon/d	long tons per day (2240 lbs)	Sm3/m	Standard cubic meters per minute
lb/gal	pounds per US gallon	m3/s	cubic meters per second	Sm3/h	Standard cubic meters per hour
oz/in3	Ounces per cubic in	m3/m	cubic meters per minute	Sm3/d	Standard cubic meters per day
kg/m3	kilograms per cubic meter	m3/h	cubic meter per hour	Sft3/s	Standard cubic feet per second US System
kg/l	kilograms per liter	m3/d	cubic meters per day	Sft3/m	Standard cubic feet per minute US System
g/cm3	grams per cubic centimeter	ft3/s	cubic feet per second	Sft3/h	Standard cubic feet per hour US System
lb/Yd3	pounds per cubic yard	ft3/m	cubic feet per minute	Sft3/d	Standard cubic feet per day US System
LT/Yd3	long tons per cubic yard	ft3/h	cubic feet per hour	Sgal/s	Standard US gallon per second
ST/Yd3	short tons per cubic yard	ft3/d	cubic feet per day	Sgal/m	Standard US gallon per minute
kg/s	kilograms per second	gal/s	US gallons per second	Sgal/h	Standard US gallon per hour
kg/m	kilograms per minute	gal/m	US gallons per minute	Sgal/d	Standard US gallon per day
kg/h	kilograms per hour	gal/h	US gallons per hour	Sbl3/s	Standard barrel per second (31.5 US gallons per barrel)
kg/d	kilograms per day	gal/d	US gallons per day	Sbl3/m	Standard barrel per minute (31.5 US gallons per barrel)

EGU	Description	EGU	Description	EGU	Description
lb/s	pounds per second	Igal/s	imperial gallons per second	Sbl3/h	Standard barrel per hour
					(31.5 US gallons per barrel)
lb/m	pounds per minute	Igal/m	imperial gallons per minute	Sbl3/d	Standard barrel per day
					(31.5 US gallons per barrel)
lb/h	pounds per hour	lgal/h	imperial gallons per hour	Sbbl/s	Standard barrel per year
					(42 US gallons per barrel)
lb/d	pounds per day	lgal/d	imperial gallons per day	Sbbl/m	Standard barrel per year
					(42 US gallons per barrel)
g/s	grams per second	bbl3/s	Barrels per second	Sbbl/h	Standard barrel per year
			(31.5 US gallons = barrel)		(42 US gallons per barrel)
g/m	grams per minute	bbl3/m	Barrels per minute	Sbbl/d	Standard barrel per year
			(31.5 US gallons = barrel)		(42 US gallons per barrel)
g/h	grams per hour	bbl3/h	Barrels per hour	mScfd	thousand of standard cubic feet per
			(31.5 US gallons = barrel)		24 hours
g/d	grams per day	bbl3/d	Barrels per day	mmScfd	millions of standard cubic feet per 24
			(31.5 US gallons = barrel)		hours
oz/s	Ounces per second	bbl/s	Barrels per second	Nm3/s	Normal Cubic meter per second
			(42 US gallons = barrel)		MKS System
oz/m	Ounces per minute	bbl/m	Barrels per minute	Nm3/m	Normal Cubic meter per minute
			(42 US gallons = barrel)		MKS System
oz/h	Ounces per hour	bbl/h	Barrels per hour	Nm3/h	Normal Cubic meter per hour MKS
			(42 US gallons = barrel)		System
oz/d	Ounces per day	bbl/d	Barrels per day	Nm3/d	Normal Cubic meter per day MKS
			(42 US gallons = barrel)		System
mTon/s	metric tons per second	l/s	liters per second	Ngal/s	Normal US gallon per second
mTon/m	metric tons per minute	l/m	liters per minute	Ngal/m	Normal US gallon per minute
mTon/h	metric tons per hour	l/h	liters per hour	Ngal/h	Normal US gallon per hour
mTon/d	metric tons per day	l/d	liters per day	Ngal/d	Normal US gallon per day
STon/s	short tons per second (2000 lbs)	Ml/h	million liters per hour	NI/s	Normal liter per second MKS System
STon/m	short tons per minute (2000 lbs)	MI/d	million liters per day	NI/m	Normal liter per minute MKS System
STon/h	short tons per hour (2000 lbs)	Mgal/d	million US gallons per day	NI/h	Normal liter per hour MKS System
STon/d	short tons per day (2000lbs)	mcfd	thousand cubic ft per day	NI/d	Normal liter per day MKS System
LTon/m	long tons per minute (2240lbs)	mmcfd	million cubic ft per day	Custom	Custom VolumeNorm-Rate
LTon/h	long tons per hour (2240lbs)	Sm3/s	Standard cubic meters per		
2.01/11	()	2	second		

### Table 13. Viscosity, K-Factor, Density, and Temperature EGU Descriptions

EGU	Description						
Viscosity	Viscosity						
PaSec	Pa.s						
cPoise	centipoise						
<b>K-Factor</b>	K-Factor						
m3/p	cubic meter per pulse						
p/l	pulses per liter						
p/ft3	pulses per cubic foot						
Temperat	Temperature						
degF	degrees Fahrenheit						
degR	degrees Rankine						
degC	degrees Celsius						
degK	degrees Kelvin						

EGU	Description
Density	
lb/ft3	pounds per cubic foot
lb/gal	pounds per US gallon
oz/in3	ounces per cubic in
kg/m3	kilograms per cubic meter
kg/l	kilograms per liter
g/cm3	grams per cubic centimeter
lb/Yd3	pounds per cubic yard
LT/Yd3	long tons per cubic yard
ST/Yd3	short tons per cubic yard
Custom	Custom Density

### Setting Flow Parameters

The 2 Flow section of the Setup mode allows you to configure parameters for flow.

In 3 FlwMap, select VolFlow, BVolFlow, MassFlow, or Velocity.

#### - NOTE

Before changing the totalizer mappings from VolFlow to BVolFlow, the totalizer must be at zero.

– If there is flow, turn the totalizer off and clear it.

- If there is no flow, clear the totalizer.

Refer to "Totals Mode" on page 65 for instructions.

In 3 FlwEGU, select the desired unit of flow from the picklist. If you pick Custom, you must define your custom unit. First, enter a Label for your custom units using up to eight alphanumeric characters. Then, enter any offset (Offset) and a conversion factor (Slope) from kilograms per second (kg/s) for mass flow units or cubic meters per second (m<sup>3</sup>/s) for volume or base volume flow units to the custom units.

Example: The slope for a custom unit of  $yd^3/min$  would be 78.47704 because 78.47704  $yd^3/min = 1 m^3/s$ .

In 3 FlwURV, enter the upper range value in the flow unit just specified.

In 3 FlwDmp, select the damping factor from the picklist.

In 3 VelEGU, select the desired velocity unit from the picklist.

### Setting Tuning Parameters

The 2Tuning section of the Setup mode allows you to specify several flowmeter options.

- In 3AddDrop, configure the pulse compensation (signal conditioning) feature as On or Off.
- In 3 RdCorr, configure the Reynolds number correction feature as On or Off.
- In 3 LFCI, set the low flow cut-in parameter to the level above which the flowmeter begins to measure flow. Select an output that provides no output under no flow conditions. In 4 FlwEGU, note the flow units in which the setting selections are shown. In 4 Setting, select a setting from the picklist presented.

- NOTE

The LFCI can be automatically set by the flowmeter in the Calibration/Test mode.

## Setting Totals Parameters

The 2 Total section of the Setup mode allows you to configure each of two totalizers. This is done in 3 TotNet and 3 TotGrd.

### - NOTE

Before changing the totalizer mappings from VolFlow to BVolFlow, the totalizer must be at zero.

– If there is flow, turn the totalizer off and clear it.

- If there is no flow, clear the totalizer.

Refer to "Totals Mode" on page 65 for instructions.

For each totalizer:

- In 4 Map, map the totalizer to Volume, Mass, or BVolume.
- In 4 EGU, select the desired unit from the picklist presented.

If you pick Custom, you must define your custom unit. First, enter a Label for your custom units using up to eight alphanumeric characters. Then, enter any offset (Offset) and a conversion factor (Slope) from kilograms (for mass units) or cubic meters (for volume or base volume units) to the custom units.

Example: The slope for a custom unit of a 42 gallon barrel would be 6.2898 because  $6.2898 \text{ bbl} = 1 \text{ m}^3$ .

## Setting Output Parameters

The 2 Output section of the Setup mode allows you to configure the communications, mA output, pulse output, and display parameters.

### Communications

There is no need to map the measurements to be displayed in the I/A Series system as they are already defined. The primary measurement is flow rate (volume, base volume, or mass); the secondary measurement is net total; the tertiary measurement is grand total.

In 3 Coms, configure the communications parameters:

- In 4PolAddr, specify the poll address from the picklist of numbers from 0 through 15.
- In 4Preamb1, set the number of preambles between 2 and 20.

### mA Output

In 3 Fail, configure the mA output to go fully downscale or upscale upon a failure.

### Pulse Output (If pulse output specified)

In 3 Pulse, go to 4 Pulse and select the type of pulse output as Rate, Total, Raw, or Off. If Rate, configure the following:

• In 4 Freq, select the upper frequency end point corresponding to the highest frequency generated as 10, 100, or 1000 Hz.

If Total, configure the following:

• In 4 Pwidth, select, the pulse width as 0.5, 5, or 50 ms.

- In 4 EGU, select the units from the picklist provided.
- In 4 U/Pulse, enter the units per pulse.

If Raw, no further action is required.

## Display

Under 3Display, configure the display parameters

Under 4 Show, specify whether the reading is to be shown for each of the following measurements and, if shown, the Format (decimal point placement) of the displayed value:

- In 5 FlwVol, the volume flow output display.
- In 5 TotNet, the net totalizer reading.
- In 5 TotGrd, the grand totalizer reading.

In 4 Show1st, select the first measurement to be shown as FlwVol, Velcty, FlwBVo, FlwMas, or Raw.

In 4 Cycle, specify whether the list of measurements configured to be shown are scanned automatically (Auto) or manually (Manual).


# Setting Piping Parameters

The 2 Pipe section of the Setup mode allows you to configure the parameters related to piping.

# Piping

Under 3 Piping, configure the parameters used by the flowmeter to correct for the effects of upstream piping and disturbances on the Flowing K-Factor as follows:

- In 4 Config, select the upstream piping configuration from the following picklist (see Figure 44):
  - ♦ Straight
  - 1 EL PAR (1 elbow with shedder parallel to elbow plane)
  - 1 EL PER (1 elbow with shedder perpendicular to elbow plane)
  - 2L0PDPAR (2 elbows with shedder parallel to plane of closest elbow and distance between elbows is zero pipe diameters)
  - 2L0PDPER (2 elbows with shedder perpendicular to plane of closest elbow and distance between elbows is zero pipe diameters)
  - 2L5PDPAR (2 elbows with shedder parallel to plane of closest elbow and distance between elbows is 5 pipe diameters)
  - 2L5PDPER (2 elbows with shedder perpendicular to plane of closest elbow and distance between elbows is 5 pipe diameters)
  - Reducer
- In 4 UpDist, enter the distance to the first upstream flow disturbance in pipe diameters.



# **Pipe Bore**

In **3** BorSch, select the pipe bore from the following picklist: Sched 10, Sched 40, Sched 80, PN16, PN40, PN64, PN100, or Sanitary.

In 3 Custom, input a Kref Bias in percent (%). For example: to change Kref by 2%, enter 2.000.

# Setting Tag Parameters

The 2 Tags section of the Setup mode allows you to configure the following identification parameters:

- In 3 HrtDes, enter the device description.
- In 3 HrtTag, enter an alphanumeric description if desired.

# Setting Flowtube Parameters

The 2 NewTube section of the Setup mode allows you to configure the following flowtube parameters:

# Model

In 3 Model, enter the model number of the flowtube (16 characters maximum) as found on the flowmeter tag. It is already in the database if the flowtube and electronics were shipped as a unit.

# **Special Flowtube**

If your flowtube was customized to be different from the model number entered, you can override certain descriptions in the model code in 3 Special as follows:

- In 4 TubDia, enter the custom flowtube diameter in meters
- In 4 TubAlp enter the thermal coefficient of expansion (alpha) in m/m/°K
- In 4 LfUFac enter the low flow cut-in user factor.

#### **Reference Number**

In 3 Ref No, enter the reference number (serial number) of the flowtube (16 characters maximum) as found on the flowmeter tag. It is already in the database if the flowtube and electronics were shipped as a unit.

# **K-Factor**

In 3 K Ref, enter the K-factor as follows:

- In 4 K EGU, select p/l or p/ft3 as the unit of the K-factor.
- In 4 K Ref, enter the reference K-factor as found on the flowmeter tag.

# Changing the Password

The 2 Passwd section of the Setup mode allows you to create or change the passwords.


In 4 LoPwd, enter the new password for access to clear (reset) the net and pulse totalizers.


In 4 HiPwd, enter the new password for access to all modes.

#### - NOTE -

- 1. Passwords contain four characters.
- 2. Use four spaces to configure 'No Password'.

# Setup Menu Tree






(a) Only applies to option "T".

(b) Factor equals Pulse/Units or Units/Pulse.

(c) Not available with special (customized) flowtubes.

(d) Not available with special (customized) flowtubes, or with Schedule 160.



(a) Available with option "Y" only.

# Calibration/Test Mode

The Calibration/Test mode enables you to:

- Set the Low Flow Cut In (LFCI)
- Calibrate the 4 and 20 mA output
- Self test the flowmeter
- Use the flowmeter to test the loop.

The Calibration/Test mode can be a passcode protected mode. So after the initial configuration, you may need to enter the HiPwd to perform the procedures in this mode. See "Password" on page 60.

#### - NOTE

If you lose your password, call our Global Customer Support for assistance.

The structural diagram for the Calibration/Test mode is shown in Figure 48.

# Calibration

In 2 Calib, go to 3 SetLFCI to have the flowmeter automatically set the Low Flow Cut-In. In doing this, the flowmeter chooses the lowest level at which no signal is detected over a 20-second time interval. It is important that the flow be zero during this procedure.

#### - NOTE

This procedure may confirm your choice of LFCI setting in "Setting Tuning Parameters" on page 71. However, if it picks a different selection, it overwrites your selection.

In 2 Calib, go to 3 Cal mA to calibrate the 4 and 20 mA output.

- The **4Restore** parameter restores the factory calibration.
- The 4Cal 4mA and 4Cal20mA parameters allow the 4 to 20 mA output of the flowmeter to be calibrated or matched to the calibration of the receiving device to an accuracy of 0.005 mA.

#### 

The flowmeter has been accurately calibrated at the factory. Recalibration of the output is normally **not** required, unless it is being adjusted to match the calibration of the receiving device.

- In 4CalDate, enter the date of the last calibration if desired.
- In 4Initial, enter the initials of the last calibrator if desired.

#### Test

In 2 Test, you can self test the flowmeter and use the flowmeter to test the loop.

#### **Testing the Loop**


The flowmeter can be used as a signal source to check and/or calibrate other instruments in the control loop, such as indicators, controllers, and recorders. To do this, set the mA output (3 Set mA), rate pulse output (3 Set Hz), or digital output (3 SetDig) signals to any value within the range limits of the meter.

#### **Testing the Flowmeter**

The self test parameter (3SelfTst) checks the flowmeter operation by injecting, near the front end of the electronics, an internally generated periodic signal of known frequency. The frequency of this signal is in turn measured and checked against the injected signal.

#### - NOTE

It is recommended that you clear the totalizer after a self test. Refer to "Totals Mode" on page 65 for instructions.



#### Figure 48. Calibration/Test Menu Tree

3. Operation Via Local Display

(a) Not available with Option "U".

(b) Not available with special orders.

# Error Messages

# **Operation Error Messages**

This section defines error messages that may be displayed and actions that can be taken to correct the error. Some messages appear periodically while seeing a valid flow measurement. This typically occurs when 'soft' limits have been exceeded and the flowmeter is warning that a hard limit is approaching.

Message	Explanation	Corrective Action
Override	The flowmeter is being overridden by an external host such as another configurator or control system.	None - This is an awareness message that the flowmeter is being overridden
W: Input xxxxxxxx	Warning: An input to a specific measurement or calculation has exceeded the normal limit and is in the 'soft limit' region. The measurement or calculation is defined on the second line of the message.	<ol> <li>Check inputted temperature flowing temperature to make sure it is within the temperature limits of the sensor.</li> <li>Check the raw frequency to determine if it is out of limits for the flowmeter size.</li> </ol>
B: Input xxxxxxxx	Bad Input: Same as above except the inputs have now exceeded the 'soft' limit. This adversely affects all measurements.	Same as above.
W: Input Total	Warning: The total (pulse, net, or grand) may not be correct due to a momentary loss of power.	Clear the total. Pulse and Net total can be cleared independently. Clearing the grand total clears pulse and net totals also.
FcErr E:0x####	An internal function did not execute successfully.	If this occurs at startup, an invalid configuration exists. Recheck the configuration. If this does not resolve the problem, re-enter the Model.

#### Table 14. Operation Error Messages

# Configuration Error Messages

Message	Explanation	Corrective Action
WrProtct	The write protect jumper is in the 'protect' position or is missing. The configuration cannot be changed unless the jumper is in the 'write' position.	Install or move the write protect jumper to the 'write' position. See "Setting the Write Protect Jumper" on page 45.
Cfg Err MsCode	An incorrect model code has been entered.	Enter the correct model code.
No Pulse Hardware	An incorrect model code has been entered. The model code entered was for a flowmeter with a pulse output. The electronics module does not have a pulse output PWB.	Enter the correct model code which begins with 84F-E, 84W-E, 84F-U (Styles A and B), or 84W-U.
Bad URV URV=URL	The entered URV has exceeded the URL (meter capacity) of the flowmeter.	Press Enter to change the URV to the value of the URL. Make sure that the entered value for Flowing Density is correct.
Bad URV URV=Min	The entered URV is less than the minimum value allowed for the URV.	Press Enter to change the URV to the minimum value allowed. Make sure that the LFCI setting and the value for Flowing Density is correct. See Note ( (a)).
FcErr E:0x####	An internal function did not execute successfully.	Review the inputs associated with the last menu function. If this does not resolve the problem, re-enter the Model.


Table 15. Configuration Error Messages


a. The minimum URV value is three times (3x) the LFCI flow rate. For applications where the URV is very low relative to the flowmeter capacity, this error message may appear when this constraint is violated. This could be the result of lowering the URV, increasing the LFCI setting, or decreasing the flowing density (increasing the corresponding LFCI flow rate values).

# 4. Operation Via HART Communicator


# Online Menu

Figure 49. 84 Vortex Flowmeter Online Menu Tree (1 of 4)





#### Figure 50. 84 Vortex Flowmeter Online Menu Tree (2 of 4)



#### Figure 51. 84 Vortex Flowmeter Online Menu Tree (3 of 4)

Figure 52. 84 Vortex Flowmeter Online Menu Tree (4 of 4)

(U)—	Model Code		
•	Serial Number		
	K Factor		
	PV USL		
	PV Min Span		
	LFCI		
	LFCI Index		
	PV Units		
	Net Total Units		
	Grand Total Units		
	AO/PV Map		
	AO/PV URV		
	AO/PV LRV		
	Pulse Mode		
	PO/PV Map*		
	PO/PV URV*		
	PO/PV LRV*		
	Pulse Max Freq*		
	Pulse Map**		
	Pulse Width**		
	Pulse Total EGU**		
	Pulse Resolution**		
	O/P Alarm Code		
	PV Damp		
	Pulse Add/Drop		

Fluid Name
Fluid Type
Temperature Units
Process Temperature
Density Units
Process Density
Base Density
Abs Viscosity Units
Process Viscosity
Mating Pipe
Piping Config
Upstream Distance
Custom K Bias
Manufacturer
Dev ID
Тад
Descriptor
Message
Date
Universal Rev
Fld Dev Rev
Software Rev
Software Sub-Revision
Hardware Rev
Poll Addr
Num Req Preams

\* If Pulse mode = Rate \*\* If Pulse Mode = Total

# Explanation of Parameters

#### - NOTE

The fast-key path shown is based on a frequently used configuration. If certain parameters are configured off or infrequently used parameters configured on, the fast-key path may be different.

Parameter	Fast-Key Path	Explanation	
Abs Viscosity Unit	1,4,1,4,8	Select the viscosity unit from the picklist provided.	
Abs Viscosity Units	1,5	Shows the absolute viscosity unit.	
Analog Output	1,4,4,2	Path to configuring the analog output.	
AO Status	1,2,6,6	Shows the AO status.	
AO Value	1,2,6,7	Shows the AO value	
AO/PV LRV	1,4,4,2,3 1,5	Shows the AO/PV LRV.	
AO/PV Map	1,4,4,2,1 1,5	Shows whether the PV is mapped to Volume Flow, Mass Flow, BVolFlow, or Velocity.	
AO/PV URV	1,4,4,2,2 1,5	Shows the AO/PV URV.	
Auto LFCI	1,2,2	Procedure for the flowmeter to automatically set the LFCI.	
Base Density	1,4,1,4,7 1,5	In Detailed Setup, enter the base density in the density unit specified. This is only used to calculate the base volumes. In Review, shows the base density.	
Basic Setup	1,3	Path to basic setup parameters.	
Calibration	1,2,5 1,4,4,2,5	Path to performing a D/A trim or scaled D/A trim.	
Custom K Bias	1,4,1,5,4 1,5	In Detailed Setup, enter the custom K-factor (with sign in percent). In Review, shows the custom K-Factor.	
Custom Dens Label	1,4,1,4,5	Enter the label for your custom density unit.	
Custom Dens Offset	1,4,1,4,5	Enter any offset.	
Custom Dens Slope	1,4,1,4,5	Enter a conversion factor for the custom density unit.	
Custom PV Label	1,3,6 1,4,1,2,2	Enter the label for your custom PV unit.	
Custom PV Offset	1,3,6 1,4,1,2,2	Enter any offset.	
Custom PV Slope	1,3,6 1,4,1,2,2	Enter a conversion factor for the custom PV unit.	
D/A Trim	1,2,5,1 1,4,4,2,5,1	Procedure to trim the 4 and 20 mA output values of the flowmeter to match the output of a plant standard measurement device.	
Date	1,2,5,3 1,4,5,5 1,4,4,2,5,3	In Diag/Service, enter the date of the last calibration. In Detailed Setup, enter the date of the last calibration.	
	1,5	In Review, shows the last calibration date.	
Density Units	1,4,1,4,5 1,5	In Detailed Setup, select the density unit from the picklist provided. In Review, shows the density units.	
Descriptor	1,4,5,3 1,5	In Detailed Setup, enter the descriptor (16 characters maximum). In Review shows the descriptor.	
Detailed Setup	1,4	Path to detailed setup parameters.	
Detail Status	1,2,7	Path to viewing the status of various device parameters.	

1,4,3,3 1,5In Detailed Setup, confirm or change the LFCI. In Review, shows the LFCI.LFCI Index6 1,5Shows the low flow cut-in picklist number.LFCI Adjust Factor1,4,2,5,3Enter the low flow cut-in user factor.Local Display1,4,4,6Path to configuring the local display.Loop Test1,2,4Procedure to use the flowmeter as a calibration source to check other instruments in the loop.Manufacturer1,4,5,1 1,5Shows the manufacturer as Invensys.Mating Pipe1,4,1,5,1 1,5In Detailed Setup, select the type of mating pipe from the picklist provided. In Review, shows the type of mating pipe.	Parameter	Fast-Key Path	Explanation	
Device Info         1,4,5         Path to configuring the device description parameters.           Device Setup         Path to all other parameters.         Device Warn Status         1,2,7,3           Diagle Service         1,2         Path to status, test, and calibration parameters.           Digital Output         1,4,4,6,3         Specify whether the list of measurements configured to be displayed are scanned automatically or manually.           Error Reason         1,2,7,1         Shows the error reason code.           Fild Dev Rev         1,5         Shows the software version of the vortex flowmeter.           Flow Velocity         1,2,6,1         Shows the software version of the vortex flowmeter.           Flow Velocity         1,2,6,1         Shows the software version of the vortex flowmeter.           Flow Velocity         1,2,6,1         Shows the software version of the vortex flowmeter.           Fluid Name         1,4,1,4,2         Path to configuring the flowtube parameters.           Fluid Type         1,5         Shows the fluid parameters.           Fluid Type         1,5         Shows the fluid parameters.           Fluid Type         1,4,1,4,2         In Detailed Setup, neath to configuring the grand total.           Grand Octal Map         1,4,1,3,2,1         Map the Grand Total to Volume, Mass, or EVolume.           Grand Total Map         1	Device Err Status	1,2,7,2	Shows the device error status.	
Device Setup         Path to all other parameters.           Device Warn Status         1,2,7,3         Shows the device warning status.           Diag/Service         1,2         Path to status, test, and calibration parameters.           Digital Output         1,4,4,1         Path to configuring the digital output.           Display Cycle         1,4,4,6,3         Specity whether the list of measurements configured to be displayed are scamed automatically or manually.           Error Reason         1,2,7,1         Shows the software version of the vortex flowmeter.           Flo Dev Rev         1,5         Shows the flow velocity value.           Flowtube Configuration         1,4,2         Path to configuring the flowtube parameters.           Fluid Name         1,4,1,4         In Detailed Setup, enter the name of the fluid.           Fluid Type         1,5         Shows the fluid type.           Grand Operations         1,2,1,4         Procedure to start, pause or clear the grand total.           Grand Total         1,1,5         in Detailed Setup, path to configuring the grand total.           Grand Total Map         1,4,1,3,2,1         Map the Grand Total to Volume, Mass, or BVolume.           Grand Total Value         1,2,1,3         Shows the grand total units.           Grand Total Value         1,2,6,4         Shows the Corrected value.	Dev ID	1,5	Shows the device identification number.	
Device Warn Status         1,2,7,3         Shows the device warning status.           Digda Output         1,4,4,1         Path to status, test, and calibration parameters.           Digital Output         1,4,4,1         Path to status, test, and calibration parameters.           Digital Output         1,4,4,6,3         Specify whether the list of measurements configured to be displayed are scanned automatically or manually.           Error Reason         1,2,7,1         Shows the error reason code.           Fld Dev Rev         1,5         Shows the flow velocity value.           Flow Volocity         1,2,6,1         Shows the flow velocity value.           Flow Volocity         1,4,2         Path to configuring the flowtube parameters.           Fluid Name         1,4,1,2         In Detailed Setup, enter the name of the fluid.           Fluid Type         1,5         Shows the fluid name.           Grand Operations         1,2,1,4         Procedure to start, pause or clear the grand total.           Grand Total         1,4,1,3,2         In Detailed Setup, path to configuring the grand total mapping and units.           Grand Total Map         1,4,1,3,2,2         In Detailed Setup, select the grand total units.           Grand Total Value         1,2,6,4         Shows the K Corrected value.           K Corrected Status         1,2,6,5         Shows the K Corrected	Device Info	1,4,5	Path to configuring the device description parameters.	
Diag/Service     1,2     Path to status, test, and calibration parameters.       Digital Output     1,4,4,1     Path to configuing the digital output.       Display Cycle     1,4,4,6,3     Specify whether the list of measurements configured to be displayed are scanned automatically or manually.       Error Reason     1,2,7,1     Shows the error reason code.       Fid Dev Rev     1,5     Shows the for velocity value.       Flow Velocity     1,2,6,1     Shows the for velocity value.       Flowtube Configuration     1,4,2     Path to configuring the flowtube parameters.       Fluid Name     1,4,1,4,2     In Detailed Setup, enter the name of the fluid.       1,5     Shows the fluid type.       Grand Operations     1,2,1,4     Procedure to start, pause or clear the grand total.       1,4,1,3,2     In Pocess Variables, shows the grand total.       1,4,1,3,2     In Pocess Variables, shows the grand total mapping and units.       Grand Total     1,4,1,3,2,1     In Detailed Setup, path to configuring the grand total mapping and units.       Grand Total Map     1,4,1,3,2,2     In Detailed Setup, select the grand total units from the picklist provided.       In Review, shows the grand total units.     1,5     Shows the Varue.       Grand Total Map     1,4,1,3,2,2     In Detailed Setup, select the grand total units.       Grand Total Value     1,2,6,3     Shows the Varue.	Device Setup		Path to all other parameters.	
Digital Output         1.4.4.1         Path to configuring the digital output.           Display Cycle         1.4.4.6.3         Specify whether the list of measurements configured to be displayed are scamed automatically or manually.           Error Reason         1.2.7.1         Shows the error reason code.           Fld Dev Rev         1.5         Shows the software version of the vortex flowmeter.           Flow Velocity         1.2.6.1         Shows the flow velocity value.           Flowtube Configuration         1.4.2         Path to configuring the flowtube parameters.           Fluid Name         1.4.1.4.2         In Detailed Setup, enter the name of the fluid.           In Flowide.         1.5.         Shows the fluid harme.           Fluid Type         1.5.         Shows the fluid harme.           Fluid Type         1.5.         In Process Variables, shows the grand total.           Grand Total         1.1.5         In Detailed Setup, path to configuring the grand total.           Grand Total Map         1.4.1.3.2.2.1         Map the Grand Total Volume, Mass, or BVolume.           Grand Total Value         1.2.1.3         Shows the grand total value.           Hardware Rev         1.5.         Shows the K Corrected value.           K Corrected         1.2.6.5         Shows the K Corrected value.           K Corrected Status	Device Warn Status	1,2,7,3	Shows the device warning status.	
Display Cycle         1,4,4,6,3         Specify whether the list of measurements configured to be displayed are scanned automatically or manually.           Error Reason         1,2,7,1         Shows the error reason code.           Fid Dev Rev         1,5         Shows the software version of the vortex flowmeter.           Flow Velocity         1,2,6,1         Shows the flow velocity value.           Flow toelocity         1,4,2         Path to configuring the flowtube parameters.           Fluid Name         1,4,1,4,2         In Detailed Setup, enter the name of the fluid.           Fluid Type         1,5         Shows the fluid type.           Grand Operations         1,2,1,4         Procedure to start, pause or clear the grand total.           In Patield Setup, path to configuring the grand total         In Process Variables, shows the grand total.           Grand Total         1,1,5         In Detailed Setup, path to configuring the grand total mapping and units.           Grand Total Units         1,4,1,3,2,2         In Detailed Setup, shows the grand total units from the picklist provided.           In Review, shows the grand total units.         In Provided.         In Provided.           Grand Total Value         1,2,6,4         Shows the vortex flowmeter hardware revision level.           HART Output         1,4,4,4         Path to configuring the HART output.           K Corrected	Diag/Service	1,2	Path to status, test, and calibration parameters.	
are scanned automatically or manually.Error Reason1.2.7.1Shows the error reason code.Fild Dev Rev1.5Shows the software version of the vortex flowmeter.Fild Dev Rev1.2.6.1Shows the flow velocity value.Flowtube Configuration1.4.2.Path to configuring the flowtube parameters.Fluid Name1.4.1.4.2In Detailed Setup, enter the name of the fluid.1.5Shows the fluid type.Grand Operations1.2.1.4Procedure to start, pause or clear the grand total.Grand Total1.1.5In Process Variables, shows the grand total.Grand Total Map1.4.1.3.2.1Map the Grand Total to Volume, Mass, or BVolume.Grand Total Value1.4.1.3.2.2In Detailed Setup, path to configuring the grand total mapping and units.Grand Total Value1.2.1.3.2.2In Detailed Setup, select the grand total units from the picklist provided.In Review, shows the grand total value.In Patiew, shows the grand total value.HART Output1.4.4.4Path to configuring the HART output.K Corrected Status1.2.6.4Shows the K-Corrected value.K Factor1.3.6.1In Dag/Service, shows the K-Factor.1.4.2.2In Dag/Service, shows the K-Factor.1.5.4In Review, shows the K-Factor.1.5.5In Review, shows the K-Factor.1.4.2.2In Dag/Service, shows the K-Factor.1.5.4In Detailed Setup, path to selecting the K-Factor unit.HART Output1.4.4.4Path to configuring the selecting the K-Factor.1.5.6Shows th	Digital Output	1,4,4,1	Path to configuring the digital output.	
Fid Dev Rev       1,5       Shows the software version of the vortex flowmeter.         Flow Velocity       1,2,6,1       Shows the flow velocity value.         Flow Lube Configuration       1,4,2       Path to configuring the flowtube parameters.         Fluid Name       1,4,1,4,2       In Detailed Setup, enter the name of the fluid.         Fluid Type       1,5       Shows the fluid type.         Grand Operations       1,2,1,4       Procedure to start, pause or clear the grand total.         Grand Total       1,4,1,1,5       In Detailed Setup, path to configuring the grand total mapping and units.         Grand Total Map       1,4,1,3,2       In Detailed Setup, select the grand total units from the picklist provided.         Grand Total Units       1,4,1,3,2,2       In Detailed Setup, select the grand total units.         Grand Total Value       1,2,1,3       Shows the grand total value.         Hardware Rev       1,5       Shows the vortex flowmeter hardware revision level.         HAT Output       1,4,4,4       Path to corriguring the HART output.         K Corrected Status       1,2,6,5       Shows the K Corrected value.         K Corrected Status       1,2,6,3       In Diag/Service, shows the K-Factor value.         K Factor Units       1,3,4       In Basic Setup, path to selecting the K-Factor unit.         1,3,4 <t< td=""><td>Display Cycle</td><td>1,4,4,6,3</td><td></td></t<>	Display Cycle	1,4,4,6,3		
Flow Velocity       1,2,6,1       Shows the flow velocity value.         Flowtube Configuration       1,4,2       Path to configuring the flowtube parameters.         Fluid Name       1,4,1,4,2       In Detailed Setup, enter the name of the fluid.         In Process Variables.       In S       Shows the fluid name.         Fluid Type       1,5       Shows the fluid type.         Grand Operations       1,2,1,4       Procedure to start, pause or clear the grand total.         Grand Total       1,1,5       In Process Variables, shows the grand total.         I.4,1,3,2       In Detailed Setup, path to configuring the grand total mapping and units.         Grand Total Map       1,4,1,3,2,1       Map the Grand Total to Volume, Mass, or BVolume.         Grand Total Units       1,4,1,3,2,2       In Detailed Setup, select the grand total units from the picklist provided.         In Review, shows the grand total units.       Shows the vortex flowmeter hardware revision level.         HART Output       1,4,4,4       Path to configuring the HART output.         K Corrected Status       1,2,6,3       Shows the K Corrected value.         K Corrected Status       1,2,6,3       In Diag/Service, shows the K-Factor.         K Factor Units       1,3,3       In Basic Setup, enter the K-Factor.         I,4,2,2       In Detailed Setup, confirm or change the LFCI.<	Error Reason	1,2,7,1	Shows the error reason code.	
Flowtube Configuration       1.4.2       Path to configuring the flowtube parameters.         Fluid Name       1.4.1,4.2       In Detailed Setup, enter the name of the fluid.         Fluid Type       1.5       Shows the fluid name.         Fluid Type       1.5       Shows the fluid type.         Grand Operations       1.2,1,4       Procedure to start, pause or clear the grand total.         Grand Total       1.1,5       In Process Variables, shows the grand total.         I.4,1,3,2       In Detailed Setup, path to configuring the grand total mapping and units.         Grand Total Map       1.4,1,3,2,1       Map the Grand Total to Volume, Mass, or EVolume.         Grand Total Units       1.4,1,3,2,2       In Detailed Setup, select the grand total units from the picklist provided.         Grand Total Value       1.2,1,3       Shows the grand total units.         Grand Total Value       1.2,1,3       Shows the vortex flowmeter hardware revision level.         HART Output       1.4,4,4       Path to configuring the HART output.         K Corrected       1.2,6,5       Shows the K Corrected value.         K Corrected Status       1.2,6,6       Shows the K-Factor.         K Factor       1.3,3       In Detailed Setup, confirm or charge the LFGI.         LFCI       5       In Detailed Setup, path to selecting the K-Factor unit.	Fld Dev Rev	1,5	Shows the software version of the vortex flowmeter.	
Fluid Name       1,4,1,4,2       In Detailed Setup, enter the name of the fluid. In Review, shows the fluid name.         Fluid Type       1,5       Shows the fluid type.         Grand Operations       1,2,1,4       Procedure to start, pause or clear the grand total.         Grand Total       1,1,5       In Process Variables, shows the grand total.         Grand Total       1,1,5,1       In Detailed Setup, path to configuring the grand total mapping and units.         Grand Total Map       1,4,1,3,2,2       In Detailed Setup, select the grand total units from the picklist provided.         Grand Total Units       1,4,1,3,2,2       In Detailed Setup, select the grand total units.         Grand Total Value       1,2,1,3       Shows the grand total value.         Hardware Rev       1,5       Shows the vortex flowmeter hardware revision level.         HART Output       1,4,4,4       Path to configuring the HART output.         K Corrected Status       1,2,6,3       In Diag/Service, shows the K-Factor value.         K Factor       1,2,6,3       In Detailed Setup, path to selecting the K-Factor.         I,4,2,3       In Detailed Setup, path to selecting the K-Factor unit.         I,4,2,3       In Detailed Setup, path to selecting the K-Factor unit.         I,4,2,3       In Detailed Setup, path to selecting the K-Factor unit.         I,4,2,3       In Detaile	Flow Velocity	1,2,6,1	Shows the flow velocity value.	
1,5In Review, shows the fluid name.Fluid Type1,5Shows the fluid type.Grand Operations1,2,1,4Procedure to start, pause or clear the grand total.Grand Total1,1,5In Process Variables, shows the grand total.1,4,1,1,5In Detailed Setup, path to configuring the grand total mapping and units.Grand Total Map1,4,1,3,2,1Map the Grand Total to Volume, Mass, or BVolume.Grand Total Units1,4,1,3,2,2In Detailed Setup, select the grand total units from the picklist provided. In Review, shows the grand total units.Grand Total Value1,2,1,3Shows the grand total value.Hardware Rev1,5Shows the vortex flowmeter hardware revision level.HART Output1,4,4,4Path to configuring the HART output.K Corrected1,2,6,5Shows the K Corrected value.K Corrected Status1,2,6,5Shows the K Corrected value.K Factor1,2,6,3In Diag/Service, shows the K-Factor value.In Beaic Setup, path to selecting the K-Factor unit. 1,3,4In Detailed Setup, path to selecting the K-Factor unit.LFCI5In the Main Menu, shows the I/-Factor. 1,5LFCI Index6Shows the low flow cut-in value.In Detailed Setup, confirm or change the LFCI. 	Flowtube Configuration	1,4,2	Path to configuring the flowtube parameters.	
Grand Operations         1,2,1,4         Procedure to start, pause or clear the grand total.           Grand Total         1,1,5         In Process Variables, shows the grand total.           In Line         1,4,1,3,2         In Detailed Setup, path to configuring the grand total mapping and units.           Grand Total Map         1,4,1,3,2,2         In Detailed Setup, select the grand total units from the picklist provided.           Grand Total Units         1,4,1,3,2,2         In Detailed Setup, select the grand total units.           Grand Total Value         1,2,1,3         Shows the grand total value.           Hardware Rev         1,5         Shows the vortex flowmeter hardware revision level.           HART Output         1,4,4,4         Path to configuring the HART output.           K Corrected Status         1,2,6,5         Shows the K Corrected value.           K Corrected Status         1,2,6,5         Shows the K-Factor value.           1,5         In Diag/Service, shows the K-Factor.         In Basic Setup, path to selecting the K-Factor unit.           1,4,2,3         In Detailed Setup, path to selecting the K-Factor unit.         In Detailed Setup, path to selecting the K-Factor unit.           1,5         In the Main Menu, shows the LFCI.         In Detailed Setup, confirm or change the LFCI.           LFCI         5         In the Main Menu, shows the LFCI. <t< td=""><td>Fluid Name</td><td></td><td></td></t<>	Fluid Name			
Grand Total       1,1,5       In Process Variables, shows the grand total.         In Process Variables, shows the grand total.       In Detailed Setup, path to configuring the grand total mapping and units.         Grand Total Map       1,4,1,3,2,1       Map the Grand Total to Volume, Mass, or BVolume.         Grand Total Units       1,4,1,3,2,2       In Detailed Setup, select the grand total units from the picklist provided. In Review, shows the grand total units.         Grand Total Value       1,2,1,3       Shows the vortex flowmeter hardware revision level.         HARTOutput       1,4,4,4       Path to configuring the HART output.         K Corrected       1,2,6,5       Shows the K Corrected value.         K Corrected Status       1,2,6,5       Shows the K-Factor value.         In Basic Setup, path to selecting the K-Factor unit.       In Detailed Setup, onter the K-Factor.         1,5       In Detailed Setup, path to selecting the K-Factor unit.         1,4,2,3       In Detailed Setup, path to selecting the K-Factor unit.         1,5       In the Main Menu, shows the UFCI.         LFCI       5       In the Main Menu, shows the UFCI.         LFCI Index       6       Shows the low flow cut-in user factor.         LFCI Index       6       Shows the low flow cut-in user factor.         LFCI Index       1,4,4,6       Path to configuring the local display. <td>Fluid Type</td> <td>1,5</td> <td>Shows the fluid type.</td>	Fluid Type	1,5	Shows the fluid type.	
1.4.1.1.5 1.4.1.3,2In Detailed Setup, path to configuring the grand total mapping and units.Grand Total Map1,4.1,3,2.1Map the Grand Total to Volume, Mass, or BVolume.Grand Total Units1.4.1,3,2.2 1.5In Detailed Setup, select the grand total units from the picklist 	Grand Operations	1,2,1,4	Procedure to start, pause or clear the grand total.	
Grand Total Map1,4,1,3,2,1Map the Grand Total to Volume, Mass, or BVolume.Grand Total Units1,4,1,3,2,2In Detailed Setup, select the grand total units from the picklist provided. In Review, shows the grand total units.Grand Total Value1,2,1,3Shows the grand total value.Hardware Rev1,5Shows the vortex flowmeter hardware revision level.HART Output1,4,4,4Path to configuring the HART output.K Corrected1,2,6,5Shows the K Corrected value.K Corrected Status1,2,6,5Shows the K Corrected statusK Factor1,2,6,3In Diag/Service, shows the K-Factor value. In Detailed Setup, enter the K-Factor. In Basic Setup, path to selecting the K-Factor unit. In Detailed Setup, path to selecting the K-Factor unit.LFCI5In the Main Menu, shows the LFCI. In Review, shows the LFCI.LFCI Index6Shows the low flow cut-in value. In Review, shows the LFCI.LFCI Adjust Factor1,4,2,3Enter the low flow cut-in picklist number.LFCI Adjust Factor1,4,4,6Path to configuring the local display.Loop Test1,2,4Procedure to use the flowmeter as a calibration source to check other instruments in the loop.Manufacturer1,4,5,1In Detailed Setup, select the type of mating pipe from the picklist provided. In Review, shows the LFCI.	Grand Total	1,4,1,1,5		
Grand Total Units1,4,1,3,2,2 1,5In Detailed Setup, select the grand total units from the picklist provided. In Review, shows the grand total units.Grand Total Value1,2,1,3Shows the grand total value.Hardware Rev1,5Shows the vortex flowmeter hardware revision level.HART Output1,4,4,4Path to configuring the HART output.K Corrected1,2,6,5Shows the K Corrected value.K Corrected Status1,2,6,3In Diag/Service, shows the K-Factor value.K Factor1,2,6,3In Diag/Service, shows the K-Factor.1,3,4In Basic Setup, enter the K-Factor.1,5In Review, shows the K-Factor.1,5In Review, shows the K-Factor.1,5In Review, shows the K-Factor.1,5In Review, shows the K-Factor.1,4,2,3In Detailed Setup, path to selecting the K-Factor unit.LFCI5In the Main Menu, shows the low flow cut-in value.1,4,3,3In Detailed Setup, confirm or change the LFCI.1,5In Review, shows the LFCI.1,5In Review, shows the LFCI.1,5In Review, shows the ISP(I)LFCI Adjust Factor1,4,2,51,2,4Procedure to use the flowmeter as a calibration source to check other instruments in the loop.Manufacturer1,4,5,11,5In Detailed Setup, select the type of mating pipe from the picklist provided.In Series1,2,4In Detailed Setup, select the type of mating pipe.			units.	
1,5provided. In Review, shows the grand total units.Grand Total Value1,2,1,3Shows the grand total value.Hardware Rev1,5Shows the vortex flowmeter hardware revision level.HART Output1,4,4,4Path to configuring the HART output.K Corrected1,2,6,4Shows the K Corrected value.K Corrected Status1,2,6,5Shows the K Corrected statusK Factor1,2,6,3In Diag/Service, shows the K-Factor value.1,3,4In Basic Setup, enter the K-Factor.1,5In Detailed Setup, path to selecting the K-Factor unit.1,5In Detailed Setup, path to selecting the K-Factor unit.1,4,2,2In Detailed Setup, path to selecting the K-Factor unit.LFCI5In the Main Menu, shows the low flow cut-in value.1,5In Review, shows the LFCI.1,5In Review, shows the LFCI.LFCI Index6Shows the low flow cut-in picklist number.LFCI Adjust Factor1,4,2,5LFCI Adjust Factor1,4,2,5Local Display1,4,4,6Path to configuring the local display.Loop Test1,2,4Procedure to use the flowmeter as a calibration source to check other instruments in the loop.Mating Pipe1,4,1,5,1In Detailed Setup, select the type of mating pipe from the picklist provided.1,5In Detailed Setup, select the type of mating pipe.	•			
Hardware Rev1.5Shows the vortex flowmeter hardware revision level.HART Output1,4,4,4Path to configuring the HART output.K Corrected1,2,6,4Shows the K Corrected value.K Corrected Status1,2,6,5Shows the K Corrected statusK Factor1,2,6,3In Diag/Service, shows the K-Factor value.1,3,4In Basic Setup, enter the K-Factor.1,4,2,3In Detailed Setup, enter the K-Factor.1,5In Review, shows the K-Factor.1,5,5In Basic Setup, path to selecting the K-Factor unit.1,4,2,2In Detailed Setup, path to selecting the K-Factor unit.LFCI5In the Main Menu, shows the low flow cut-in value.1,4,3,3In Detailed Setup, confirm or change the LFCI.LFCI Index6Shows the low flow cut-in picklist number.LFCI Adjust Factor1,4,2,5,3Enter the low flow cut-in picklist number.LFCI Adjust Factor1,4,4,6Path to configuring the local display.Loop Test1,2,4Procedure to use the flowmeter as a calibration source to check other instruments in the loop.Mating Pipe1,4,1,5,1In Detailed Setup, select the type of mating pipe from the picklist provided.In Detailed Setup, shows the type of mating pipe.1,4,1,5,1	Grand Total Units		provided.	
HART Output1,4,4.4Path to configuring the HART output.K Corrected1,2,6,4Shows the K Corrected value.K Corrected Status1,2,6,5Shows the K Corrected statusK Factor1,2,6,3In Diag/Service, shows the K-Factor value.1,3,4In Basic Setup, enter the K-Factor.1,4,2,3In Detailed Setup, enter the K-Factor.1,5In Basic Setup, path to selecting the K-Factor unit.LFCI5In betailed Setup, confirm or change the LFCI.1,4,2,2In Detailed Setup, confirm or change the LFCI.LFCI5In the Main Menu, shows the Low flow cut-in value.1,5In Petailed Setup, confirm or change the LFCI.LFCI Index6Shows the low flow cut-in picklist number.LFCI Adjust Factor1,4,2,3Enter the low flow cut-in user factor.Local Display1,4,4,6Path to configuring the local display.Loop Test1,2,4Procedure to use the flowmeter as a calibration source to check other instruments in the loop.Maufacturer1,4,1,5,1In Detailed Setup, select the type of mating pipe from the picklist provided.In Sting Pipe1,4,1,5,1In Detailed Setup, select the type of mating pipe.	Grand Total Value	1,2,1,3	Shows the grand total value.	
K Corrected1,2,6,4Shows the K Corrected value.K Corrected Status1,2,6,5Shows the K Corrected statusK Factor1,2,6,3In Diag/Service, shows the K-Factor value.1,3,4In Basic Setup, enter the K-Factor.1,4,2,3In Detailed Setup, enter the K-Factor.1,5In Review, shows the K-Factor.K Factor Units1,3,31,4,2,2In Detailed Setup, path to selecting the K-Factor unit.1,4,2,2In Detailed Setup, path to selecting the K-Factor unit.LFCI51,4,3,3In Detailed Setup, confirm or change the LFCI.1,5In Review, shows the low flow cut-in value.LFCI Index66Shows the low flow cut-in user factor.LCal Display1,4,4,61,2,4Procedure to use the flowmeter as a calibration source to check other instruments in the loop.Manufacturer1,4,5,11,5In Detailed Setup, select the type of mating pipe from the picklist provided.In Seriew, shows the type of mating pipe.	Hardware Rev	1,5	Shows the vortex flowmeter hardware revision level.	
K Corrected Status1,2,6,5Shows the K Corrected statusK Factor1,2,6,3In Diag/Service, shows the K-Factor value.1,3,4In Basic Setup, enter the K-Factor.1,4,2,3In Detailed Setup, enter the K-Factor.K Factor Units1,3,3In Basic Setup, path to selecting the K-Factor unit.LFCI5In Detailed Setup, path to selecting the K-Factor unit.LFCI5In the Main Menu, shows the low flow cut-in value.In Detailed Setup, confirm or change the LFCI.1,5LFCI Index61,5Shows the low flow cut-in picklist number.LFCI Adjust Factor1,4,2,3LA4,6Path to configuring the local display.Loop Test1,2,4Manufacturer1,4,5,11,5In Detailed Setup, select the type of mating pipe from the picklist provided.In Detailed Setup, shows the type of mating pipe.	HART Output	1,4,4,4	Path to configuring the HART output.	
K Factor1,2,6,3 1,3,4 1,4,2,3 1,5In Diag/Service, shows the K-Factor value. In Basic Setup, enter the K-Factor. In Detailed Setup, enter the K-Factor. In Detailed Setup, enter the K-Factor.K Factor Units1,3,3 1,4,2,2In Basic Setup, path to selecting the K-Factor unit. In Detailed Setup, path to selecting the K-Factor unit.LFCI5 1,4,3,3 1,5In the Main Menu, shows the low flow cut-in value. In Detailed Setup, confirm or change the LFCI. In Review, shows the LFCI.LFCI5 1,5,5In the Main Menu, shows the LFCI. In Review, shows the LFCI.LFCI Index6 1,5,5Shows the low flow cut-in picklist number.LFCI Adjust Factor1,4,2,5,3Enter the low flow cut-in user factor.Local Display1,4,4,6Path to configuring the local display.Loop Test1,2,4Procedure to use the flowmeter as a calibration source to check other instruments in the loop.Manufacturer1,4,1,5,1 1,5In Detailed Setup, select the type of mating pipe from the picklist provided. In Review, shows the type of mating pipe.	K Corrected	1,2,6,4	Shows the K Corrected value.	
1,3,4In Basic Setup, enter the K-Factor.1,4,2,3In Detailed Setup, enter the K-Factor.1,5In Review, shows the K-Factor.K Factor Units1,3,31,4,2,2In Basic Setup, path to selecting the K-Factor unit.LFCI5In the Main Menu, shows the low flow cut-in value.1,4,3,3In Detailed Setup, confirm or change the LFCI.LFCI Index61,5Shows the low flow cut-in picklist number.LFCI Adjust Factor1,4,2,3Local Display1,4,4,6Loop Test1,2,4Procedure to use the flowmeter as a calibration source to check other instruments in the loop.Manufacturer1,4,1,5,11,5In Detailed Setup, select the type of mating pipe from the picklist provided.In Review, shows the type of mating pipe.	K Corrected Status	1,2,6,5	Shows the K Corrected status	
1,4,2,3 1,5In Detailed Setup, enter the K-Factor. In Review, shows the K-Factor.K Factor Units1,3,3 1,4,2,2In Basic Setup, path to selecting the K-Factor unit. In Detailed Setup, path to selecting the K-Factor unit.LFCI5 1,4,3,3 1,5In the Main Menu, shows the low flow cut-in value. In Detailed Setup, confirm or change the LFCI. In Review, shows the LFCI.LFCI Index6 1,5Shows the low flow cut-in picklist number.LFCI Adjust Factor1,4,2,5,3Enter the low flow cut-in user factor.Local Display1,4,4,6Path to configuring the local display.Loop Test1,2,4Procedure to use the flowmeter as a calibration source to check other instruments in the loop.Mating Pipe1,4,1,5,1 1,5In Detailed Setup, select the type of mating pipe.	K Factor			
1,5In Review, shows the K-Factor.K Factor Units1,3,3 1,4,2,2In Basic Setup, path to selecting the K-Factor unit. In Detailed Setup, path to selecting the K-Factor unit.LFCI5 1,4,3,3 1,5In the Main Menu, shows the low flow cut-in value. In Detailed Setup, confirm or change the LFCI. In Review, shows the LFCI.LFCI Index6 1,5Shows the low flow cut-in picklist number.LFCI Adjust Factor1,4,2,5,3Enter the low flow cut-in user factor.Local Display1,4,4,6Path to configuring the local display.Loop Test1,2,4Procedure to use the flowmeter as a calibration source to check other instruments in the loop.Manufacturer1,4,1,5,1 1,5In Detailed Setup, select the type of mating pipe from the picklist provided. In Review, shows the type of mating pipe.				
1,4,2,2In Detailed Setup, path to selecting the K-Factor unit.LFCI5In the Main Menu, shows the low flow cut-in value. In Detailed Setup, confirm or change the LFCI. In Review, shows the LFCI.LFCI Index6 1,5Shows the low flow cut-in picklist number.LFCI Adjust Factor1,4,2,5,3Enter the low flow cut-in user factor.Local Display1,4,4,6Path to configuring the local display.Loop Test1,2,4Procedure to use the flowmeter as a calibration source to check other instruments in the loop.Manufacturer1,4,5,1 1,5Shows the manufacturer as Invensys.1,5In Detailed Setup, select the type of mating pipe from the picklist provided. In Review, shows the type of mating pipe.				
1,4,3,3 1,5In Detailed Setup, confirm or change the LFCI. In Review, shows the LFCI.LFCI Index6 1,5Shows the low flow cut-in picklist number.LFCI Adjust Factor1,4,2,5,3Enter the low flow cut-in user factor.Local Display1,4,4,6Path to configuring the local display.Loop Test1,2,4Procedure to use the flowmeter as a calibration source to check other instruments in the loop.Manufacturer1,4,5,1 1,5Shows the manufacturer as Invensys.Mating Pipe1,4,1,5,1 1,5In Detailed Setup, select the type of mating pipe from the picklist provided. In Review, shows the type of mating pipe.	K Factor Units			
LFCI Index6 1,5Shows the low flow cut-in picklist number.LFCI Adjust Factor1,4,2,5,3Enter the low flow cut-in user factor.Local Display1,4,4,6Path to configuring the local display.Loop Test1,2,4Procedure to use the flowmeter as a calibration source to check other instruments in the loop.Manufacturer1,4,5,1 1,5Shows the manufacturer as Invensys.Mating Pipe1,4,1,5,1 1,5In Detailed Setup, select the type of mating pipe from the picklist provided. In Review, shows the type of mating pipe.	LFCI	1,4,3,3	In Detailed Setup, confirm or change the LFCI.	
Local Display1,4,4,6Path to configuring the local display.Loop Test1,2,4Procedure to use the flowmeter as a calibration source to check other instruments in the loop.Manufacturer1,4,5,1 1,5Shows the manufacturer as Invensys.Mating Pipe1,4,1,5,1 1,5In Detailed Setup, select the type of mating pipe from the picklist provided. In Review, shows the type of mating pipe.	LFCI Index	-		
Local Display1,4,4,6Path to configuring the local display.Loop Test1,2,4Procedure to use the flowmeter as a calibration source to check other instruments in the loop.Manufacturer1,4,5,1 1,5Shows the manufacturer as Invensys.Mating Pipe1,4,1,5,1 1,5In Detailed Setup, select the type of mating pipe from the picklist provided. In Review, shows the type of mating pipe.	LFCI Adjust Factor		Enter the low flow cut-in user factor.	
Loop Test1,2,4Procedure to use the flowmeter as a calibration source to check other instruments in the loop.Manufacturer1,4,5,1 1,5Shows the manufacturer as Invensys.Mating Pipe1,4,1,5,1 1,5In Detailed Setup, select the type of mating pipe from the picklist provided. In Review, shows the type of mating pipe.	-		Path to configuring the local display.	
1,5Mating Pipe1,4,1,5,1In Detailed Setup, select the type of mating pipe from the picklist provided. In Review, shows the type of mating pipe.			Procedure to use the flowmeter as a calibration source to check	
provided.1,5In Review, shows the type of mating pipe.	Manufacturer		Shows the manufacturer as Invensys.	
	Mating Pipe		provided.	
Measurement Status 11.2.6 [Path to viowing the status of various measurement parameters	Measurement Status	1,2,6	Path to viewing the status of various measurement parameters.	

Parameter Fast-Key Path		Explanation		
Measuring Elements	1,4,1	Path to configuring the measuring element parameters.		
Message	1,4,5,4 1,5	In Detailed Setup, enter the message (32 characters max). In Review shows the message.		
Model Code	1,3,1 1,4,2,1 1,5	In Basic Setup, enter the model code. In Detailed Setup, enter the model code. In Review, shows the model code.		
Net Operations	1,2,1,2	Procedure to start, pause or clear the net total.		
Net Total	1,1,4 1,4,1,1,4 1,4,1,3,1	In Process Variables, shows the net total. In Process Variables, shows the net total. In Detailed Setup, path to configuring the net total mapping and units.		
Net Total Map	1,4,1,3,1,1	Map the Net Total to Volume, Mass, or BVolume.		
Net Total Units	1,4,1,3,1,2	In Detailed Setup, select the net total units from the picklist provided. In Review, shows the net total units.		
Net Total Value	1,5	Shows the net total value.		
Num Req Preams	1,4,4,4,2	In Detailed Setup, configure the number of preambles to be sent in a response message from the flowmeter to the host. In Review, shows the number of preambles.		
	1,5			
O/P Alarm Code	1,4,4,5	In Detailed Setup, configure the output to go fully upscale or downscale if a failure occurs.		
Output Configuration	1,5	In Review, shows the O/P Alarm Code.		
Output Configuration	1,4,4	Path to configuring the output parameters.		
p/CuFt	1,3,3,2	Sets the K-Factor unit to pulses per cubic foot.		
p/l	1,3,3,1	Sets the K-Factor unit to pulses per liter.		
Piping	1,4,1,5	Path to configuring the piping parameters.		
Piping Config	1,4,1,5,2 1,5	In Detailed Setup, select the type of piping configuration from the picklist provided. In Review shows the type of piping configuration.		
PO/PV LRV	1,4,4,3,4	Shows the PO/PV LRV.		
	1,5			
PO/PV Map	1,4,4,3,2 1,5	Shows whether the PV is mapped to Volume Flow, Mass Flow, BVolFlow, or Velocity.		
PO/PV URV	1,4,4,3,3 1,5	Shows the PO/PV URV.		
Poll Addr	1,4,4,4,1	In Detailed Setup, configure the poll address to a number from 0 through 15. A nonzero number applies to multidrop applications. In Review, shows the poll address.		
Primary Display	1,4,4,6,2	Select the first measurement to be displayed.		
Process Density	1,4,1,4,6	In Detailed Setup, enter the flow density in the density unit specified. In Review, shows the process density.		
	1,5			
Process Parameters	1,4,1,4	Path to configuring the process parameters.		
Process Temperature	1,4,1,4,4 1,5	In Detailed Setup, enter the flow temperature in the temperature unit specified. In Review, shows the process temperature.		
Process Variables	1,1 1,4,1,1	Path to viewing the process variable values.		
Process Viscosity	1,2,6 1,4,1,4,9 1,5	In Diag/Service, shows the process viscosity value. In Detailed Setup, enter the base viscosity in the viscosity unit specified. In Review, shows the process viscosity.		

Parameter	Fast-Key Path	Explanation		
Pulse Add Drop	1,4,3,2	In Detailed Setup, configure the pulse compensation (signal conditioning) feature On or Off. In Review, shows the pulse compensation as On or Off.		
Pulse Map	1,4,4,3,2 1,5	Shows whether the pulse is mapped to Volume Flow, Mass Flow, BVolFlow, or Velocity.		
Pulse Max Freq	1,4,4,3,5	In Detailed Setup, set the upper frequency end point corresponding to the highest frequency as 10, 100, or 1000 Hz. In Review, shows the pulse maximum frequency.		
	1,5			
Pulse Mode	1,4,4,3,1	In Detailed Setup, select the type of pulse output as Rate, Total, Raw, or Off.		
Pulse Operations	1,5	In Review, shows the type of pulse output.		
Pulse Out		Procedure to start, pause or clear the pulse total. Shows the pulse value.		
Pulse Out Pulse Output	1,2,6,8	Path to configuring the pulse output.		
Pulse Resolution	1,4,4,3			
Pulse Status	1,4,4,3,5	Enter the units per pulse.		
Pulse Total EGU	1,2,6,9	Shows the pulse status.		
Pulse Width	1,4,4,3,4	Select the unit from the picklist provided.		
	1,4,4,3,3	Select the pulse width as 0.5, 5, or 50 ms.		
PV	2 1,1,1 1,4,1,1,1	Shows the value of the process variable.		
PV % Rnge	1,1,2 1,4,1,1,2	Shows the process variable in percent of range.		
PV AO	3 1,1,3 1,4,1,1,3	Shows the analog output of the process variable.		
PV Configuration	1,4,1,2	Path to configuring the PV parameters.		
PV Damp	1,5	Shows the damping time.		
PV Damping	1,3,8 1,4,1,2,4	Enter the damping time if different than the one shown.		
PV Map	1,3,5 1,4,1,2,1	Map the PV to Volume Flow, Mass Flow, BVolFlow, or Velocity.		
PV Min Span	1,5	Shows the minimum span.		
PV Units	1,3,6 1,4,1,2,2 1,5	In Basic Setup, select the PV units from the picklist. In Detailed Setup, select the PV units from the picklist. In Review, shows the PV units.		
PV URV	4 1,3,7 1,4,1,2,3	In the Basic Menu, shows the process variable upper range value. In Basic Setup, enter the PV URV. In Detailed Setup, enter the PV URV.		
PV USL	7 1,5	In the Basic Menu, shows the upper sensor limit. In Review, shows the upper sensor limit.		
Review	1,5	Path to viewing flowmeter values and settings.		
Revisions	1,4,5,6	Path to configuring the various revision levels.		
Reynolds Number	1,4,3,1	Configure the Reynolds Number correction feature On or Off.		
Scaled D/A Trim	1,2,5,2 1,4,4,2,5,2	Procedure to trim the low and high mA output values of the flowmeter to match the output of a plant standard measurement device.		
Self Test	1,2,3	Procedure to self test the device.		
Serial Number	1,4,2,4 1,5	In Detailed Setup, enter the serial number. In Review, shows the serial number.		
Set Analog Out	1,2,4,2 1,4,4,2,4	Procedure to set the analog output to 4 mA, 20 mA, or another value.		

Parameter	Fast-Key Path	Explanation		
Set Digital Out	1,2,4,1 1,4,4,1,2	Procedure to set the digital output to override the PV, net total, grand total, or vortex frequency.		
Set Fluid Defaults	1,3,2 1,4,1,4,1	Path to setting the default parameters for the type of fluid selected (liquid, gas, or steam).		
Set Pulse Out	1,2,4,3 1,4,4,3,6	Procedure to set the pulse output to 0 Hz, the maximum frequency, or another value.		
Show	1,4,4,6,1	Specify which measurements are to be displayed and their format (decimal point placement).		
Software Rev	1,5	Shows the software revision level.		
Software Sub-Revision	1,5	Shows the software sub-revision level.		
Special	1,4,2,5	Path to configuring special flowtube parameters.		
Tag	1,3,9 1,4,5,2 1,5	In Basic Setup, enter the tag (8 characters maximum). In Detailed Setup, enter the tag (8 characters maximum). In Review, shows the tag.		
Temperature Units	1,4,1,4,3 1,5	In Detailed Setup, select the temperature unit from the picklist provided. In Review, shows the temperature units.		
Total Units	1,4,1,3	Path to configuring the totals parameters.		
Totals Operations	1,2,1	Path to viewing, starting, stopping, or clearing the totalizers.		
Tube Alpha	1,4,2,5,2	Enter the thermal coefficient of expansion (alpha) in m/m/°K.		
Tube Diameter	1,4,2,5,1	Enter the custom flowtube diameters in meters.		
Tuning	1,4,3	Path to configuring the tuning parameters.		
Universal Rev	1,5	Shows the universal command set revision level.		
Upstream Distance	1,4,1,5,3	In Detailed Setup, enter the distance to the first upstream disturbance in pipe diameters. In Review, shows the upstream distance.		
Variable Map	1,4,4,1,1	Map the output as the primary, secondary, tertiary, or fourth output.		
Velocity Status	1,2,6,2	Shows the flow velocity status.		
Velocity Units	1,4,1,2,5	In Detailed Setup, select the unit from the picklist.		
Viscosity Status	1,2,6	Shows the process viscosity status.		
Vortex Freq	1,1,6 1,4,1,1,6	Shows the vortex frequency.		

# 5. Troubleshooting

# 

Components in your flowmeter are ESD sensitive and thus are susceptible to damage resulting from electrostatic discharge. Invensys recommends that you be grounded via a conductive wrist strap or by standing on an ESD mat when performing maintenance in the electronics compartment or the remote junction box, and if the housing is removed.

#### - NOTE

Before troubleshooting your vortex flowmeter, verify that the flowmeter has been correctly configured for the model, flow, and output parameters.

# Flowmeter Output Indicates Flow When There Is No Flow

In some installations, the flowmeter can indicate flow when the line is shut down. This could be the effect of a leaking valve, sloshing fluid, or noise sources such as pump-induced pipe vibration.

1. Check the Low Flow Cut-In (LFCI) setting.

The LFCI setting sets the sensitivity of the electronics to the sensor output signal. There are eight LFCI settings. The default setting leaving the factory is level 4 and is suitable for most applications. Should there be excessive vibration, resulting in false excitation of the vortex sensor, it may be necessary to increase the LFCI setting. To set the LFCI:

a. Make sure there is a no-flow condition. Preferably block valves should be closed. Control valves can leak when closed, resulting in some flow through the flowmeter that it can detect.

#### - NOTE

Setting the dampening to 0 seconds will show the magnitude of any false excitation.)

- b. Increase the LFCI setting by one level and observe the signal output. The LFCI should be increased until there is no false signal. Alternately, the AUTO LFCI command can be used. When this command is executed, the flowmeter starts at the most sensitive LFCI setting. If false signal is detected within a 20 second period, the LFCI is increased to the next level and so on until a level is reached where there is no false signal after a 20 second time period.
- c. If dampening was changed to 0 seconds, change dampening to a desired level.
- d. If the LFCI level has changed, make sure controllers and receivers can accommodate the increased LFCI setting. Output remains at 4 mA from zero flow until this flow rate is reached.

- 2. If the LFCI is higher than desired, there are several possible causes:
  - a. Check the flowmeter sizing. The flowmeter could be over-sized for the application, resulting in the need to provide a measurement at a very low flow velocity. Consult FlowExpertPro<sup>™</sup> to validate the meter sizing.
  - b. Check for excessive vibration in a plane that is parallel to the vortex sensor. The vortex sensor axis is perpendicular to the pipe diameter. See Figure 21. For most applications where the electronics are top mounted and the pipe is supported by horizontal pipe supports, this may result in false signal. In these cases, reposition the meter so the electronics are pointed to the side. The sensor axis will then be vertical.
  - c. Examine peripheral equipment and vibration sources to assure they are not imparting vibration into the vortex flowmeter.
- 3. Other sources of false signal:
  - a. Check for 60 Hz signal pickup. Check the output of the flowmeter against the expected value for a 60 Hz input signal. If 60 Hz interference is present, examine the flowmeter and interconnecting wiring for proper grounding and shielding.
  - b. If the flowmeter is remote mounted, check to see that the remote cable is properly terminated. The cable was properly terminated at the factory, but in cases where the cable was shortened (only shorten the cable at the flowtube end), check the termination (see "Electrical Installation" on page 46).

# Flowmeter Has No Output (No mA Output and the Display [If So Equipped] Is Blank)

- 1. Remove the field wiring cover and check the power supply voltage. The voltage across the + and terminals must be between 15.5 and 42 volts dc.
- 2. Make sure there is no moisture in the termination compartment. Moisture could be a result of a loose cable/conduit connection or a cover that was not fully engaged.
- 3. If voltage at the terminals is 0, check for a blown fuse in power supply or for damaged wires.
- 4. If voltage is below minimum, check the loop load vs supply voltage per Figure 33.
- 5. If voltage is correct, check the voltage on the cable inside the housing to verify the protection circuit in the terminal block assembly has not been damaged. If no voltage is present on the cable inside the housing, replace the terminal block assembly.

# Flowmeter Has No Output With Flow, But Has a 4 mA Signal and a Lighted Display (If So Equipped).

1. Check the LFCI setting. This sets the point where the mA output remains at 4 mA from zero flow to the LFCI flow rate. If flow is above this level, and there is still no change in output, proceed as follows:

- Check the flowmeter status to see it has not "failed low". The flowmeter is configurable to fail either "low" or "high". The mA value in the fail-low mode is 3.6 mA. (The mA value in the fail-high mode is 22 mA.)
- 3. Check to see that the module can output the desired mA or pulse output frequency by going to the Test mode and setting the outputs as previously described.

# Flowmeter Output Increases With Flow, However When It Approaches Full Scale, the Output Suddenly Goes To 4 mA

- 1. This is indicative of an intrinsically safe loop that is using a passive (unpowered) barrier. As the mA value increases, the voltage at the terminals has dropped below the minimum and the output has gone to 4 mA.
- 2. Install an active (externally powered) barrier such as a Pepperl+Fuchs model KFD0-SCS-Ex1.55

# Flowmeter with Remote Mounted Electronics Has No Output or Low Output With Flowing Conditions

- 1. Perform a visual analysis of the preamplifier to observe any discoloration as a result of over heating the remote mounted pre-amplifier. Check the maximum ambient temperature specification per the electrical certification table and/or the product label.
- 2. Make sure there is no moisture in the termination compartment. Moisture could be a result of a loose cable/conduit connection or a cover that was not fully engaged.
- 3. Check the voltage levels at the junction box located on top of the flow meter body. The following values should be observed:
  - a. Red to yellow: +3.0 + -0.3 volts
  - b. Orange to yellow: 3.0 +/- 0.3 volts.

If these values are not observed there is likely a break or cut in the cable between the flowmeter and the remote electronics. Or, the pre-amplifier may not be working.

- 4. Check to verify the sensor wires and cable wires are fully engaged in the clamp-type connectors. This can be done by lightly "tugging" on each wire, assuring it is securely held in place by the connector. Also check to make sure the connector is not clamping the wire insulation instead of the conductor. If any wires are not engaged, depress the lever in the connector, insert the bare conductor, and release the lever, re-checking the wire to assure it is firmly clamped.
- 5. Check for sensor output. This can be done with a small portable scope meter. There should be a sine-like wave form on the meter. This wave for does not have to be sinusoidal, but alternating output should be observed. The amplitude of the signal is dependent on sensor type and velocity. The frequency of the output should be in accordance with the expected flow rate.
- 6. Check the pre-amplifier:

- a. Disconnect the sensor leads
- b. For a standard temperature sensor, connect a 2200 pF +/- 5% 50V NPO ceramic capacitor to the + (brown) terminal of the sensor terminal block.
- c. Connect a portable frequency generator that can supply a sinusoidal 0.5 volt peakto-peak signal to the sensor input terminals.
- d. Compute the expected sensor frequency for the flow rate going through the flowmeter. (Use FlowExpertPro for making this determination, or compute the frequency based on the meter K-factor (this is stamped on the flowmeter body).
- e. Re-check the output at the remote electronics. If there is output at the electronics, the sensor is likely not working and needs to be replaced.
- f. If there is no output at the remote electronics, proceed to check the pre-amplifier by disconnecting the blue and yellow wires from the remote cable. (Note: the orange and red wires need to stay connected to provide power to the pre-amplifier.) Connect the scope meter to the blue and yellow (+ and -) terminals on the output terminal block. The amplitude of the signal should be approximately the same amplitude (0.5 volts) of the input signal and the same frequency.
- g. For flowmeters with an extended temperature sensor, replace the 2200 pF capacitor with a 22pF capacitor. Set the frequency input amplitude to 0.5 volts peak to peak. The output from the preamplifier should be 1.5X the input value or 0.75 volts peak to peak, and be at the same frequency as the input.
- h. If the output from the pre-amplifier is correct, proceed to check out the cable for breaks or cuts, and verify the remote cable is correctly connected to the junction box at the flowmeter.
- i. The remote cable is factory-terminated and sealed at the electronics end. The cable cannot be removed or re-terminated at the electronics end. If the cable has been tampered with at the electronics end, this is likely the root cause of the improperly working flowmeter and requires replacement.
- j. If the flowmeter still has no output, proceed to the electronics module test.

# **Electronics Module Test**

- 1. Remove the electronics compartment cover at the remote electronics.
- 2. Make sure there is no moisture in the electronics compartment. Moisture could be a result of a loose cable/conduit connection or a cover that was fully engaged. A build up of corrosive moisture in this compartment could affect the performance of the electronics. Also examine the electronics for exposure to excessive heat. The maximum temperature the electronics can withstand is 80°C (176°F). Make sure the installation is such that the electronics do not exceed this temperature.
- 3. Test the mA or pulse output by putting the flowmeter in the Test mode and setting either the mA or pulse output value. If the meter has no output in this test mode, replace the module. If there is output from the meter, proceed to the next step.
- 4. Remove the electronics from the compartment by loosing the two captured screws.
- 5. Check the inside for broken or pinched wires and/or connectors that are not engaged.

- 6. Check the voltage level at the cable end of the blue and red wires. The voltage should be the same as was measured on the field terminals. Should there be a difference, the terminal block electronics assembly may have been damaged in a severe transient (lightening strike).
- 7. Remove the 4-wire connector from the back of the electronics module. This is the signal input connector from the sensor to the electronics module. In place of this connector, connect a test connector (part number K0152KU).
- 8. Connect a frequency generator to the brown (+) and yellow (-) wires. Inject a sinusoidal 0.5 V peak to peak signal that is in the vortex shedding frequency range for the flowmeter. Observe there is a change in the 4-20 mA or rate pulse output signal. Change the input frequency over the expected vortex frequency range and verify the output changes accordingly.
- 9. If there is still no output, replace the electronics module.

# Flowmeter Has Incorrect Output

- 1. Output is lower than expected at all flow rates
  - a. Verify that the upper range value (URV) is correct.
  - b. Verify that the zero and span of the mA output is correct.
  - c. Check for vibration levels, that may influence the output signal. This is best accomplished by following the procedure for setting the low flow cut-in in "Flowmeter Output Indicates Flow When There Is No Flow" on page 93.
  - d. Check the flowmeter configuration to verify that the fluid flowing density is entered correctly. An incorrect configuration could result in band pass filters being set to improper values, with in-band signals being adversely affected.
  - e. Check the load resistance.
  - f. In the test mode, verify that the mA output at the receivers is correct.
- 2. Output is lower than expected at low-flow rates.

Check the steps in the above test, however if the problem only appears at low flow rates, the likelihood is that there is a pulsating flow condition, resulting in missed pulses when the fluid velocity is very low.

- 3. Output is constant when flow is increasing or decreasing.
  - a. This condition is likely the result of an in-band noise source. Where the vortex signal is being over-ridden by the noise source.
  - b. Check the LFCI setting procedure. Check the URV value to make sure that it is in line with the actual measurement range.
- 4. Output is greater than the expected value.
  - a. Test the above.
  - b. Verify that the flowmeter is not in a "fail safe" mode where full scale output has been configured as the fail safe output condition.
  - c. Verify the URV is correctly configured.

- 5. Incorrect pulse output value.
  - a. Check the configuration of the pulse output to verify that it is correct.
    - Raw Pulse: the raw vortex shedding frequency.
    - Rate Pulse: verify that the rate pulse is configured to the correct full range value of 10 Hz, 100 Hz, or 1000 Hz.
    - Total pulse: verify that the total pulse is properly defined.
  - b. If rate pulse is configured, set the output frequency in the test mode and verify the correct value.

# 6. Maintenance

# 

Components in your flowmeter are ESD sensitive and thus are susceptible to damage resulting from electrostatic discharge. Invensys recommends that you be grounded via a conductive wrist strap or by standing on an ESD mat when performing maintenance in the electronics compartment or the remote junction box, and if the housing is removed.

# Introduction

The operation of the 84F-T (Styles A and B), 84F-U (Styles A and B), 84W-T, and 84W-U Vortex Flowmeters consists of three basic functions: (1) generation and shedding of vortices in the fluid stream, (2) sensing of vortices, and (3), amplification, conditioning, and processing of the signal from the vortex sensor. Should a malfunction of the flowmeter be suspected, the cause can normally be isolated to one of these three functions.

Personnel involved in maintenance of vortex meters should be trained and qualified in the use of the equipment required and in the removal and replacement of the meter in the piping. They should also be qualified for the routine maintenance of the meter components.

# Vortex Generation and Shedding

The process of vortex generation and shedding can be degraded or destroyed by disturbances in the upstream flow, the nature of the flowing fluid, or by damage to the vortex shedding element (rare). Such flow disturbances may be created by gaskets protruding into the flowing stream, by some form of partial blockage in the upstream piping, by the piping configuration, or by the existence of two-phase flow. Should the vortex shedding element become heavily caked, coated, or physically damaged to the extent that its basic shape or dimensions are changed, the vortex shedding process may be impaired. Also, the length of straight, unobstructed run of upstream piping is important (refer to "Upstream and Downstream Disturbances" on page 33).

# Vortex Sensing

There are two basic types of sensors employed by both the 84F and 84W Vortex Flowmeters -Standard Temperature and Extended Temperature Range. The Standard Temperature Range sensor may be filled with Fluorolube for applications with process temperature limits of -20 to +90°C (0 to 200°F) or with Silicone oil for applications with process temperature limits of -20 to +200°C (0 to 400°F). The Extended Temperature Range sensor is an unfilled sensor for applications to 430 °C (800 °F).

The Standard Temperature Range sensor consists of a piezoelectric bimorph crystal that is sealed inside a liquid-filled capsule having two diaphragms on opposing sides. The vortex shedding process creates an alternating differential pressure across the capsule that is transmitted via the diaphragms and fill-fluid to the crystal.

The Extended Temperature Range sensor consists of two piezoelectric crystals sealed inside a capsule having two process diaphragms, on opposing sides, connected internally by a mechanical shuttle. The vortex shedding process creates an alternating differential pressure across the capsule that is transmitted via the diaphragm-shuttle mechanism to the crystals.

The alternating force acting on the crystals causes them to develop a pulsed voltage with a frequency equal to the vortex shedding frequency. Damage to sealing diaphragms or other physical damage could cause the sensors to operate improperly.

# Electronic Module

The electronic module is housed in the flowmeter housing opposite the side labeled FIELD TERMINALS. On the back of the module are three terminal blocks. See Table 16 for a summary of the terminal block connections.

No. of Connectors	Color	Description
2	Red Blue	Loop + Loop -
2	Yellow Green	Pulse Out + Pulse Out -
4	Blue (B) Red (R) Orange (O) Yellow (Y)	Sensor + or Preamp Out + Preamp Power + Preamp Power - Sensor - or Preamp Out -

Table 16.	Electronic	Module	Terminal	Block	Connections
10000 100	Diccillonite 3	1,10000000	101 110010000	Diocit	00111100110

#### 

Integrally mounted flowmeters with standard temperature range do **not** have a preamplifier. Integrally mounted flowmeters with extended temperature range and all remotely mounted flowmeters **do** have a preamplifier.

# Electronic Module Removal

Refer to Figure 53.

#### - WARNING -

Before proceeding, ensure that power is removed from the flowmeter.


- 1. For flowmeters with housing cover locks, screw the electronic compartment cover lock screw into the housing to unlock the cover.
- 2. Remove electronic module compartment threaded cover.

#### - NOTE -

If the cover cannot be removed by hand, insert a flat bar in the cover slot.

- 3. If a display is mounted to the electronic module, remove the display by loosening the two mounting screws and unplugging the ribbon cable from the electronic module.
- 4. Unscrew the two captive screws, one on each side of the electronic module.

- 5. Pull the electronic module out of the housing far enough to be able to disconnect the wires from the terminal blocks on the back of the electronic module.
- 6. Disconnect the mA output (red blue), pulse output (yellow green), and preamplifier/sensor (blue red orange yellow) cable connectors from the 2-, 3-, and 4-pin terminal blocks respectively.
- 7. Remove the electronic module from the housing.



### Figure 53. Electronic Module Connections

# Electronic Module Replacement

Refer to Figure 53.

# 

Before proceeding, ensure that power is removed from the flowmeter.

1. Remove the electronic module. See "Electronic Module Removal" on page 100.

# 

The replacement electronic module is shipped in a protective antistatic plastic bag. Do **not** remove it from this bag **until** it is ready to be installed in a flowmeter. This minimizes the possibility of damage due to accidental electrostatic discharge.

- 2. Remove the new electronic module from its protective bag.
- 3. Connect the mA output (red blue) and pulse output (yellow green), and preamplifier/sensor (blue red orange yellow) cable connectors to the 2-, 3-, and 4-pin terminal blocks respectively on the back of the electronic module.
- 4. Back the two electronic module captive screws out of the module until the screws are captured by the plastic housing.
- 5. Turning the electronic module one turn maximum to take up the slack in the wires, locate the module in the housing over the two mounting holes. Making sure that no wires are pinched under the module, tighten the captive mounting screws.

6. If the electronic module was equipped with a display, reinstall the display. Carefully fold the ribbon cable in the space between display and the electronic module so that it is not pinched. The display molding should rest firmly against the module molding before tightening the screws. See Figure 54.

# Figure 54. Display Connection

- 7. The new electronic module must be configured to match the one just removed.
- 8. Perform the "Post-Assembly Dielectric Test" on page 107.
- 9. Replace the electronic compartment cover. On flowmeters with housing cover locks, relock the electronic compartment cover **before** operating the flowmeter.

# Neck Board Replacement

All 84F and 84W Series Vortex Flowmeters have a printed wiring board located in the neck of the instrument. This board (henceforth referred to as a neck board) functions as a preamplifier, barrier and/or interface depending on the specific model.

Preamplifier Board: In integrally mounted flowmeters with extended temperature range.

Barrier Board: In flowmeters with explosionproof/flameproof electrical certification. These flowmeters also have a PE ground in the electronics housing which must be disconnected as part of the preamplifier replacement procedure.

Interface Board: In all 84 Series flowmeters.


# **Removal Procedure**

#### - WARNING

Before proceeding, ensure that power is removed from the flowmeter.

- 1. Remove the electronic module. See "Electronic Module Removal" on page 100.
- 2. If your flowmeter has explosionproof/flameproof electrical certification, disconnect the two wires from the PE ground screw in the electronics housing.
- 3. If your housing has an anti-rotation screw, remove the red lacquer from the screw recess. Turn the screw three full turns counterclockwise (see Figure 31 for location). Remove the housing by rotating it counterclockwise (when viewed from the top).
- 4. If your housing has a retention clip, remove the red lacquer from the screw recess. Remove the screw completely, and slide the clip off the housing. Save the clip and screw for future use. Remove the housing by rotating it counterclockwise (when viewed from the top).
- 5. Disconnect the wires from the 4-position terminal block on the neck board.
- 6. Remove the two screws securing the neck board in its cup and remove the board from the cup. Save the screws (and barrier if applicable).

I



# Installation Procedure

# - WARNING

Before proceeding, ensure that power is removed from the flowmeter.

#### - NOTE

The replacement neck board is shipped in a protective antistatic plastic bag. Do **not** remove the preamplifier from this bag **until** it is ready to be installed in a flowmeter. This prevents damage due to accidental electrostatic discharge.

- 1. Remove the neck board. See "Removal Procedure" on page 103.
- 2. Feed the (2 or 4) wires from the cup through the hole in the center of the neck board and connect them to the 4-position terminal block on the board.
- 3. Install the neck board into its cup and secure it (and the barrier if applicable) with the two screws previously removed.
- 4. Feed the electronics cable (and the PE ground wire if applicable) through the housing neck and into the electronics compartment.
- 5. Inspect the cup O-ring for damage. If the O-ring is damaged, replace it with the appropriate O-ring (see parts list for your transmitter). Lubricate the O-ring with silicone lubricant (Invensys Part Number 0048130 or equivalent). Verify that the O-ring is situated in the groove of the neck.

#### - WARNING

Failure to reuse or install the proper "Cup" O-ring for CSA labeled product violates ANSI / ISA 12.27.01.

- 6. Screw the housing onto the cup. Hand tighten until it bottoms. Do not over tighten.
- 7. If your housing has an anti-rotation screw, engage the anti-rotation screw until it touches the cup and back it off 1/8th turn. It is important that the screw is not touching the cup. Fill the screw recess with red lacquer (Invensys Part Number X0180GS or equivalent). the housing may then be rotated up to one full turn counterclockwise for optimum access.
- 8. If your housing has a retention clip, insert the clip over the boss in the housing neck so that the hole in the clip is aligned with the hole in the boss. Install the screw but do not tighten. Rotate the housing up to one full turn counterclockwise for optimum access. Tighten the retention clip screw and fill the screw recess with red lacquer (Invensys Part Number X0180GS or equivalent). The housing can still be rotated for optimum access.
- 9. If your flowmeter has explosionproof/flameproof electrical certification, reconnect the two (green) PE ground wires to the PE ground screw in the electronics housing.
- 10. Connect the mA output (red blue) and pulse output (yellow green), and electronics (blue red orange yellow) cable connectors to the 2-, 3-, and 4-pin terminal blocks respectively on the back of the electronic module.
- 11. Back the two captive screws out of the module until the screws are captured by the plastic housing.
- 12. Rotate the module one-half to one full turn to slightly twist the wires together.
- 13. Locate the electronic module over the mounting holes, assure that no wires are pinched, and tighten the captive mounting screws.
- 14. Perform the "Post-Assembly Dielectric Test" on page 107.
- 15. Replace the electronic compartment cover. On flowmeters with housing cover locks, relock the electronic compartment cover **before** operating the flowmeter.

# Preamplifier Replacement

With integrally mounted electronics, the preamplifier is located on the neck board. See "Neck Board Replacement" on page 102.

With remotely mounted electronics, use the following procedure referring to Figure 56.


# **Removal Procedure**

#### - WARNING -

Before proceeding, ensure that power is removed from the flowmeter.

- 1. On flowmeters with a junction box cover lock, remove the lock.
- 2. Remove the junction box threaded cover.
- NOTE -

If the cover cannot be removed by hand, insert a flat bar in the cover slot.



3. Disconnect the (blue-red-orange-yellow) preamplifier wires from the 4-position terminal block and the (yellow and brown) sensor wires from the 2-position terminal block.

#### 

Note the position of the wires because the placement of colored wires in the correct position on the new preamplifier board is important.

4. Remove the preamplifier by removing the two screws securing it. Save the screws.

# Installation Procedure

# 

Before proceeding, ensure that power is removed from the flowmeter.

#### - NOTE

The replacement preamplifier is shipped in a protective antistatic plastic bag. Do **not** remove the preamplifier from this bag **until** it is ready to be installed in a flowmeter. This prevents damage due to accidental electrostatic discharge.

1. Remove the preamplifier. See "Removal Procedure" on page 106.


#### - NOTE


There are two preamplifier boards - be sure to install the correct board. L0123HT for a standard temperature flowmeter and L0123HV for an extended temperature flowmeter.

- 2. Connect the (yellow and brown) sensor wires to the 2-position terminal block and the (blue-red-orange-yellow) preamplifier wires to the 4-position terminal block.
- 3. Mount the new preamplifier in the junction box using the two screws you saved when removing the old preamplifier.
- 4. Perform the "Post-Assembly Dielectric Test" below.
- 5. Replace the threaded junction box cover. On flowmeters with cover locks, relock the junction box cover **before** operating the flowmeter.

# Post-Assembly Dielectric Test

To ensure there are no faults to ground in any of the internal wiring, apply 500 V ac or 707 V dc dielectric strength test for one minute between shorted input terminals and housing ground as shown in Figure 57.





# Sensor Replacement

The flowmeter does not need to be removed from the pipeline for sensor replacement. The pipeline must, however, be shut down and emptied before loosening the bonnet bolts.

Replacing the sensor does not cause a shift in the K-factor. Therefore, the flowmeter does not require recalibration.

#### -! CAUTION

The placement of colored wires in the correct position in the terminal blocks is important. Verify correctness.

# Integrally Mounted Flowmeter

Refer to Figure 58.

# Sensor Assembly Removal

- WARNING -

Before proceeding, ensure that power is removed from the flowmeter.

- 1. Remove the electronic module. See "Electronic Module Removal" on page 100.
- 2. If your flowmeter has explosionproof/flameproof electrical certification, disconnect the two wires from the PE ground screw in the electronics housing.
- 3. Disconnect the conduit from the housing. Remove the terminal compartment cover and the wiring from the field wiring terminal block.
- 4. If your housing has an anti-rotation screw, remove the red lacquer from the screw recess. Turn the screw three full turns counterclockwise (see Figure 31 for location). Remove the housing by rotating it counterclockwise (when viewed from the top).
- 5. If your housing has a retention clip, remove the red lacquer from the screw recess. Remove the screw completely, and slide the clip off the housing. Save the clip and screw for future use. Remove the housing by rotating it counterclockwise (when viewed from the top).
- 6. Disconnect the (yellow and brown) sensor wires from the 4-position terminal block on the neck board. If your flowmeter has explosionproof/flameproof electrical certification, loosen the screw and rotate the metal barrier out of the way first.
- 7. Remove the bonnet bolts and lift off the electronic housing, bonnet, and sensor assembly as a unit.
- 8. Slide the sensor assembly out of the bonnet.

## Sensor Assembly Installation

#### - NOTE

Before beginning the assembly procedure, verify that you have the correct kit of parts. Kit part numbers can be found in PL 008-714 for Style A and PL 008-753 for Style B.

The sensor kits consist of:

- ♦ 1 Sensor assembly
- 1 Sensor seal kit (containing an O-ring, gasket, flow dam, and 4 bonnet bolts)
- ♦ 2 Tie wraps
- ♦ 1 Instruction

#### 

Before proceeding, ensure that power is removed from the flowmeter.

- 1. If the flow dam has remained in the flowmeter body, remove it before starting to reassemble. Also make sure that the O-ring chamfer in the bonnet is clean and doesn't contain any pieces of the old O-ring.
- 2. Slide the new O-ring over the sensor wires and onto the neck of the sensor.
- 3. Place the **new** flat gasket over the sensor in contact with serrated sealing surface. Center the gasket. Slide the **new** flow dam into the groove of the sensor.
- 4. Feed the sensor wires through the hole in the bonnet until the sensor is touching the bonnet and the wires extend through the hole in the center of the neck board.

#### - NOTE


It may be helpful to use a straw as a tool to do this. Slide a straw over the sensor wires and feed the straw through the bonnet and neck board. Then remove the straw.

5. Insert the sensor with the bonnet into the flowmeter body and secure with four **new** bonnet bolts finger tight.

## 


Style A bolts cannot be used for Style B Vortex meters. Check corresponding Parts List document, and contact Invensys with any questions.

Do **not** use the bonnet bolts in the sensor replacement kits for 84F-xxxxxL flowmeters (dual measurement with isolation valves). Use four X0173TF bolts as shown in the parts list.



It is important that the gasket be sealed uniformly to provide a good seal. The following two steps assure a uniform seal. Failure to follow these steps could result in personal injury due to gasket leakage.

6. Tighten all bonnet bolts to 2.8 N·m (2 lb·ft) per the sequence shown in Figure 59.



- 7. Continue to tighten the bolts to 7 N·m (5 lb•ft) using the same sequence.
- 8. Continue to tighten as follows:
  - a. For Model 84 Style A flowmeter, continue to tighten in steps of 7 N·m (5 lb·ft) using the same sequence. The maximum torque needed for safe operation is 34 N·m (25 lb·ft).
  - b. For 84F Style B flowmeter, tighten to 40.7 N•m (30 lb•ft).
- 9. Connect the (yellow and brown) sensor wires to the 4-position terminal block on the neck board. If your flowmeter has explosionproof/flameproof electrical certification, rotate the metal barrier into place and tighten its mounting screw. Lightly tug on each sensor wire to assure that the wire is firmly clamped in the terminal block. Also check that it is clamped on the metal conductor and not on the insulation.
- 10. Feed the electronics cable (and the PE ground wire if applicable) through the housing neck and into the electronics compartment.
- 11. Inspect the cup O-ring for damage. If the O-ring is damaged, replace it with the appropriate O-ring (see parts list for your transmitter). Lubricate the O-ring with silicone lubricant (Invensys Part Number 0048130 or equivalent). Verify that the O-ring is situated in the groove of the neck.

### 

Failure to reuse or install the proper "Cup" O-ring for CSA labeled product violates ANSI / ISA 12.27.01.

- 12. Screw the housing onto the cup. Hand tighten until it bottoms. Do not over tighten.
- 13. If your housing has an anti-rotation screw, engage the anti-rotation screw until it touches the cup and back it off 1/8th turn. It is important that the screw is not touching the cup. Fill the screw recess with red lacquer (Invensys Part Number X0180GS or equivalent). the housing may then be rotated up to one full turn counterclockwise for optimum access.

- 14. If your housing has a retention clip, insert the clip over the boss in the housing neck so that the hole in the clip is aligned with the hole in the boss. Install the screw but do not tighten. Rotate the housing up to one full turn counterclockwise for optimum access. Tighten the retention clip screw and fill the screw recess with red lacquer (Invensys Part Number X0180GS or equivalent). The housing can still be rotated for optimum access.
- 15. If your flowmeter has explosionproof/flameproof electrical certification, reconnect the two (green) PE ground wires to the PE ground screw in the electronics housing.
- 16. Connect the mA output (red blue) and pulse output (yellow green), and electronics (blue red orange yellow) cable connectors to the 2-, 3-, and 4-pin terminal blocks respectively on the back of the electronics module. Apply tie wraps as required.
- 17. Back the two electronic module captive screws out of the module until the screws are captured by the plastic housing.
- 18. Turning the electronic module one turn maximum to take up the slack in the wires, locate the module over the mounting holes. Making sure that no wires are pinched under the module, tighten the captive mounting screws.
- 19. If the electronic module was equipped with a display, reinstall the display. Carefully fold the ribbon cable in the space between the display and the electronic module so that it is not pinched. The display molding should rest firmly against the module molding before tightening the screws.
- 20. Reconnect the conduit to the housing and the wiring to the field wiring terminal block.
- 21. Replace the electronic compartment cover. On flowmeters with housing cover locks, relock the electronic compartment cover **before** operating the flowmeter.

#### - WARNING

In order to maintain agency certification of this product and to prove the integrity of the parts and workmanship in containing process pressure, a hydrostatic pressure test **must** be performed. The meter must hold for one minute without leaking the appropriate pressure from Table 17.

Model	End Connection	Test Pressure		
		316 SS (1.5X MWP)	Duplex SS, Nickel alloy CX2MW (equivalent to Hastelloy <sup>®</sup> C-22 (a)) (1.5X MWP)	Carbon Steel (MWP)
84F	ANSI Class 150	413 psi	435 psi	428 psi
	ANSI Class 300	1080 psi	1125 psi	1110 psi
	ANSI Class 600	2160 psi	2250 psi	2220 psi
	ANSI Class 900	3240 psi	3375 psi	3330 psi
	ANSI Class 1500	5400 psi	5625 psi	5558 psi
	PN16	2.4 MPa	2.4 MPa	2.4 MPa
	PN25	3.8 MPa	3.8 MPa	3.8 MPa
	PN40	6.0 MPa	6.0 MPa	6.0 MPa
	PN63	9.5 MPa	9.5 MPa	9.5 MPa
	PN100	15.0 MPa	15.0 MPa	15.0 MPa
	PN160	24.0 MPa	24.0 MPa	24.0 MPa
84W	All	15 MPa (2250 psi)		

Table 17. Maximum Test Pressure

a. Hastelloy® is a registered trademark of Haynes International Inc.

# Remotely Mounted Flowmeter

Refer to Figure 60.

## Sensor Assembly Removal

Before proceeding, ensure that power is removed from the flowmeter.

- 1. On flowmeters with a junction box cover lock, remove the cover lock.
- 2. Remove the junction box threaded cover.

#### - NOTE

If the cover cannot be removed by hand, insert a flat bar in the cover slot.

- 3. Disconnect the (yellow and brown) sensor wires from the 2-position terminal block on the preamplifier.
- 4. Remove the bonnet bolts.
- 5. Lift off the junction box, bonnet, and sensor assembly as a unit.
- 6. Slide the sensor assembly out of the bonnet.

### Sensor Assembly Installation

#### - NOTE

Before beginning the replacement procedure, verify that you have the correct kit of parts. Kit part numbers can be found in PL 008-714 for Style A and PL 008-753 for Style B.

The sensor kits consist of:

- ◆ 1 Sensor assembly
- 1 Sensor seal kit (containing an O-ring, gasket, flow dam, and 4 bonnet bolts)
- ♦ 2 Tie wraps
- ♦ 1 Instruction

## 

Before proceeding, ensure that power is removed from the flowmeter.

- 1. If the flow dam has remained in the flowmeter body, remove it before starting to reassemble. Also make sure that the O-ring chamber in the bonnet is clean and doesn't contain any pieces of the old O-ring.
- 2. Slide the new O-ring over the sensor lead and onto the neck of the sensor.
- 3. Place the **new** flat gasket over the sensor in contact with the serrated sealing surface. Center the gasket. Slide the **new** flow dam into the groove of the sensor.
- 4. Feed the sensor wires through the hole in the bonnet until the sensor is touching the bonnet and the wires extend through the slot in the center of the preamplifier board.

#### - NOTE

It may be helpful to use a straw as a tool to do this. Slide a straw over the sensor wires and feed the straw through the bonnet and preamplifier board. Then remove the straw.

5. Insert the sensor with the bonnet into the flowmeter body and secure with four **new** bonnet bolts finger tight. See Figure 60.

### 

Style A bolts cannot be used for Style B Vortex meters. Check the corresponding Parts List document, and contact Invensys with any questions.

Do **not** use the bonnet bolts in the sensor replacement kits for 84F-xxxxL flowmeters (dual measurement with isolation valves). Use four X0173TF bolts as shown in the parts list.




Figure 60. Sensor Replacement - Remotely Mounted Flowmeter

It is important that the gasket be sealed uniformly to provide a good seal. The following two steps assure a uniform seal. Failure to follow these steps could result in personal injury due to gasket leakage.

- 6. Tighten all bonnet bolts to 2.8 N·m (2 lb·ft) per the sequence shown in Figure 59.
- 7. Continue to tighten the bolts to 7 N·m (5 lb•ft) using the same sequence.
- 8. Continue to tighten as follows:
  - a. For Model 84 Style A flowmeter, continue to tighten in steps of 7 N·m (5 lb·ft) using the same sequence. The maximum torque needed for safe operation is 34 N·m (25 lb·ft).
  - b. For 84F Style B flowmeter, tighten to 40.7 N·m (30 lb•ft).
- 9. Connect the (yellow and brown) sensor wires to the 2-position preamplifier terminal block.
- 10. Replace the threaded junction box cover. On flowmeters with cover locks, relock the junction box cover **before** operating the flowmeter.



In order to maintain agency certification of this product and prove integrity of the parts and workmanship in containing process pressure, a hydrostatic pressure test must be performed. The meter must hold for one minute without leaking the appropriate pressure from Table 17.

# Appendix A. Isolation Valves

Isolation valving is available in single and dual measurement versions for standard and extended range sensors. The following procedure applies to all versions. Replacing the sensor in this type of unit is essentially the same as replacing a sensor in units without isolation valving. However, particular care must be taken since the process does not need to be shut down.

## 

The isolation valve must be in the closed position prior to replacing the sensor. It must be gradually depressurized so that process fluid does not leak. Personal injury could result from such a leak. Follow normal lockout procedures. Remove power from the flowmeter.

# Replacing the Sensor

1. Close the valve. This is a dual port, single ball 1/4-turn valve. Use a wrench on the flat on the valve stem to turn clockwise one quarter turn. See Figure 62.

#### - NOTE

The right angle position indicator attached to the stem is **not** a valve handle. Use a wrench on the valve stem flats.

- 2. Allow the unit to cool down as required.
- 3. Remove power from the flowmeter.
- 4. Gradually loosen the four top bolts that connect the bonnet to the top surface of the valve body. Do **not** loosen the bottom bolts.
- 5. Allow trapped process fluid within valve body to depressurize.
- 6. Remove the bolts loosened in Step 4 and lift off the housing, bonnet, and sensor as a unit.
- 7. Replace the sensor following the instructions in "Sensor Replacement" on page 108. Be sure the O-ring is installed on the sensor and use a new flow dam and gasket.

#### 

Since it is not possible to leak test the valve-to-bonnet joint, it must be assembled carefully.

8. Open the valve counterclockwise. Use care and check for leaks.

#### - NOTE

Replacing the sensor does not cause a shift in the K-factor. Therefore, the meter does not require recalibration.

# Replacing or Installing an Isolation Valve

# Style A Vortex Flowmeters

The flowmeter does not need to be removed from the pipeline to replace the isolation valve. However, the pipeline must be shut down and emptied before loosening the mounting bolts.


- 1. If the flowmeter is wired with rigid conduit, it may be necessary to disconnect the input wiring and conduit connections.
- 2. Remove the top bolts holding the bonnet and the bottom bolts holding the valve body.
- 3. Install a new gasket and flow dam on the lower section of the valve body and assemble the valve into the flowmeter body. Refer to Figure 62 or Figure 63. These are the same gaskets and flow dams used with sensors.
- 4. Install the four bolts on the bottom flange finger tight.

#### - WARNING

It is important that the gasket be sealed uniformly to provide a good seal. The following two steps assure a uniform seal. Failure to follow these steps could result in personal injury due to gasket leakage.

5. Tighten all bonnet bolts to 2.8 N·m (2 lb·ft) per the sequence shown in Figure 61.

Figure 61. Bonnet Bolt Torquing Sequence




- 6. Continue to tighten the bolts to 6.8 N·m (5 lb•ft) using the same sequence.
- 7. Continue to tighten in steps of 7 N·m (5 lb·ft) using the same sequence. The maximum torque needed for safe operation is 34 N·m (25 lb·ft).
- 8. Install a new gasket and flow dam on the sensor. Hold the sensor, bonnet, and housing together and carefully slide the sensor into the top of the valve body.
- 9. Install the four bolts on the top flange and tighten, using the procedure explained in Steps 4 through 7.


### 


It is important that the gasket be sealed uniformly to provide a good seal. Failure to follow these steps could result in personal injury due to gasket leakage.

10. Reconnect the conduit and external wiring. Refer to "Electrical Installation" on page 46.










## Style B Vortex Flowmeters, Single Isolation Valve

The flowmeter does not need to be removed from the pipeline to replace the isolation valve. However, the pipeline must be shut down and emptied before loosening the mounting bolts.

- 1. If the flowmeter is wired with rigid conduit, it may be necessary to disconnect the input wiring and conduit connections.
- 2. Remove the top bolts holding the bonnet and the bottom bolts holding the valve body.
- 3. Prior to reassembling the single isolation valve and all related topworks components, place the adapter plate (K0153BE) on top of the flowtube and bolt using four screws (X0174FD). Torque to 30 lb•ft by tightening in increments of 6.8 N•m (5 lb•ft) using the torque sequence shown in Figure 64.
- 4. Install a new gasket and flow dam on the lower section of the isolation valve body, and push the isolation valve into the sensor pocket of the Vortex flowmeter. Refer to Figure 65. These are the same gaskets and flow dams used with sensors.
- 5. Install the four bolts on the bottom flange finger tight.

It is important that the gasket be sealed uniformly to provide a good seal. The following two steps assure a uniform seal. Failure to follow these steps could result in personal injury due to gasket leakage.

6. Tighten all bonnet bolts to 2.8 N·m (2 lb·ft) per the sequence shown in Figure 64.




- 7. Continue to tighten the bolts to 6.8 N·m (5 lb•ft) using the same sequence.
- 8. Continue to tighten in steps of 7 N·m (5 lb·ft) using the same sequence. The maximum torque needed for safe operation is 34 N·m (25 lb·ft).
- 9. Install a new gasket and flow dam on the sensor. Hold the sensor, bonnet, and housing together and carefully slide the sensor into the top of the valve body.
- 10. Install the four bolts on the top flange and tighten, using the procedure explained in Steps 6 through 8.



It is important that the gasket be sealed uniformly to provide a good seal. Failure to follow these steps could result in personal injury due to gasket leakage.

11. Reconnect the conduit and external wiring. Refer to "Electrical Installation" on page 46.





# Style B Vortex Flowmeters, Dual Isolation Valve

The flowmeter does not need to be removed from the pipeline to replace the isolation valve. However, the pipeline must be shut down and emptied before loosening the mounting bolts.

- 1. If the flowmeter is wired with rigid conduit, it may be necessary to disconnect the input wiring and conduit connections.
- 2. Remove the top bolts holding the bonnet and the bottom bolts holding the valve body.
- 3. Prior to reassembling the dual isolation manifold and all related topworks components, place the adapter plate (K0153BE) on top of the flowtube and bolt using four screws (X0174FD). Torque to 30 lb•ft by tightening in increments of 6.8 N•m (5 lb•ft) using the torque sequence shown in Figure 66.
- 4. Install a new gasket and flow dam for the end plate adapter (K0155JA), and install a new gasket and flow dam for the dual isolation manifold. These are the same gaskets and flow dams used with sensors. Refer to Figure 67.
- 5. Insert the dual isolation manifold "dummy sensor" to the end plate adapter, and push the complete assembly onto flowtube sensor pocket.
- 6. Secure the dual isolation manifold using four bolts. Torque each bolt to 25 lb•ft by tightening in increments of 6.8 N•m (5 lb•ft) using the torque sequence shown in Figure 66.
- 7. Install the four bolts on the bottom flange finger tight.



It is important that the gasket be sealed uniformly to provide a good seal. The following two steps assure a uniform seal. Failure to follow these steps could result in personal injury due to gasket leakage.

8. Tighten all bonnet bolts to 2.8 N·m (2 lb·ft) per the sequence shown in Figure 66.





Figure 66. Bonnet Bolt Torquing Sequence

- 9. Continue to tighten the bolts to 6.8 N·m (5 lb·ft) using the same sequence.
- 10. Continue to tighten in steps of 7 N·m (5 lb·ft) using the same sequence. The maximum torque needed for safe operation is 34 N·m (25 lb·ft).
- 11. Install a new gasket and flow dam on the sensor. Hold the sensor, bonnet, and housing together and carefully slide the sensor into the top of the valve body.
- 12. Install the four bolts on the top flange and tighten, using the procedure explained in Steps 7 through 10.

#### - 🔔 WARNING -

It is important that the gasket be sealed uniformly to provide a good seal. Failure to follow these steps could result in personal injury due to gasket leakage.

13. Reconnect the conduit and external wiring. Refer to "Electrical Installation" on page 46.



I

#### **ISSUE DATES**

FEB 2007	APR 2010
JUN 2008	NOV 2011
FEB 2009	JAN 2012
JAN 2010	AUG 2014

Vertical lines to the right of text or illustrations indicate areas changed at last issue date.

Invensys Systems, Inc. 10900 Equity Drive Houston, TX 77041 United States of America http://www.invensys.com



Outside U.S.: 1-508-549-2424 by Schneider Electric Website: http://support.ips.invensys.com Copyright 2007-2014 Invensys Systems, Inc. All rights reserved.

Invensys, Foxboro, and I/A Series are trademarks of L Invensys Limited, its subsidiaries, and affiliates. All other trademarks are the property of their respective owners.

Invensys is now part of Schneider Electric.

L

I.